① : Engine Room No.1 R/B

LHD : Engine Compartment Right (See Page 22)

RHD: Engine Compartment Left (See Page 22)

