# : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J2	70 (LHD)	J10	74 (LHD)	J22	78 (LHD)
J4	70 (LHD)	J14	74 (LHD)	J23	80 (LHD)
J5	70 (LHD)	J17	74 (LHD)	J24	80 (LHD)
J8	74 (LHD)	J18	74 (LHD)		
J9	74 (LHD)	J21	78 (LHD)		

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1 54 (LHD) Engine Room No.1 R/B (Engine Compartment Right) 2 55 (LHD) Engine Room No.2 R/B (Engine Compartment Left) 3 56 Engine Room No.3 R/B (Engine Compartment Left) 4 57 (LHD) Passenger Side R/B (Right Kick Panel)		Engine Room No.1 R/B (Engine Compartment Right)
		Engine Room No.2 R/B (Engine Compartment Left)
		Engine Room No.3 R/B (Engine Compartment Left)
		Passenger Side R/B (Right Kick Panel)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1C	58 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1D	30 (EHD)	Institution to a file and briver side 3/b (Left Nick Fallel)			
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)			
1G	59 (LHD)				
2D	60 (LHD)	Roof Wire and Passenger Side J/B (Right Kick Panel)			
2F	60 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)			
2G	61 (LHD)	Cowi Wife and Passenger Side 3/b (Night Nick Paller)			
3B	62				
3C	02	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)			
3E	63				
3F					
3G					
3H					

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
EA1	96 (LHD)	Engine Wire and Cowl Wire (Inside of the ECU Box)			
EA3	90 (LITID)	Linguile wife and cow wife (maide of the Loo Box)			
EB1	96 (LHD)	Cowl Wire and Relay Block Wire (Inside of the Engine Room No.3 R/B)			
EB2	90 (LITID)	Cowi wife and Nelay block wife (maide of the Engine Nooth No.3 N/b)			
IB1	98 (LHD)	Front Door LH Wire and Cowl Wire (Left Kick Panel)			
IE1 98 (LHD) Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column IG1 98 (LHD) Cowl Wire and A/C Sub Wire (Left Side of the Blower Unit)  IK1 100 (LHD) Front Door RH Wire and Cowl Wire (Right Kick Panel)  BA1 102 (LHD) Rear Door LH Wire and Floor No.2 Wire (Under the Center Pillar LH)		Cowl Wire and Cowl Wire (Left Side of the Instrument Panel Reinforcement)			
		Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)			
		Cowl Wire and A/C Sub Wire (Left Side of the Blower Unit)			
		Front Door RH Wire and Cowl Wire (Right Kick Panel)			
		Rear Door LH Wire and Floor No.2 Wire (Under the Center Pillar LH)			
		Rear Door RH Wire and Floor No.1 Wire (Under the Center Pillar RH)			
BC1	BC1 104 (LHD) Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)				
BD1	104 (LHD)	Floor No.1 Wire and Front Seat RH Wire (Under the Front Passenger's Seat)			

### : GROUND POINTS


Code	See Page	Ground Points Location
EA	96 (LHD)	Right Fender
EB	96 (LHD)	Left Fender
EC	96 (LHD)	Front Side of the Intake Manifold
ED	96 (LHD)	Rear Side of the Intake Manifold
EE	96 (LHD)	Under the ABS & TRC & VSC Actuator
IF	98 (LHD)	Left Kick Panel
IG	98 (LHD)	Behind the Combination Meter
IH	98 (LHD)	Instrument Panel Brace RH
II	98 (LHD)	Right Side of the Cowl Panel
BJ	102 (LHD)	Rear Floor Partition Panel LH
BK	102 (LHD)	Quarter Panel LH
BL	102 (LHD)	Rear Floor Partition Panel RH
BM	102 (LHD)	Quarter Panel RH

### : SPLICE POINTS


	Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
	E1	96 (LHD)	Engine Wire	16	100 (LHD)	Cowl Wire
	E4	96 (LHD)	Cowl Wire	B2	102 (LHD)	Roof Wire
Γ	l1	100 (LHD)	Cowi wile	B4	102 (LHD)	Floor No.2 Wire
Γ	l5	100 (LHD)	Engine Room Main Wire	B7	104 (LHD)	Front Seat LH Wire









(Hint: See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)



(Hint: See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)



(Hint: See Page 7, 23, 39)



(Hint: See Page 7, 23, 39)



(Hint: See Page 7, 23, 39)