CIRCUIT INSPECTION

DI28C-03

DTC	C1201[] 51[]	Engine Control System Malfunction
-----	--------------	-----------------------------------

CIRCUIT DESCRIPTION

 $If [\] rouble [\] occurs [\] n [\] he [\] engine [\] control [\] system, [\] he [\] ECU [\] prohibits [\] TRC [\] and [\] VSC [\] control.$

DTC[No.	DTC[Detecting[Condition	Trouble[Area
C1201∏ 51	Conditions[[1]]@nd[[2]]continue[for[\$]secs.: (1)[Engine[speed:[\$00[]pm[]br[]nore. (2)[A[frouble[signal[]n[]he[]engine[control[system[]s[]]nput.	•Engine[control[system

INSPECTION PROCEDURE

1 Check[the[DTC[for[the[engine[(See[page[DI-4)

*1

Repair engine control system according to the output code.

*1: Output NG code