
DI877_0

Gateway ECU (AVC-LAN adapter) circuit

WIRING DIAGRAM



INSPECTION PROCEDURE

1[]

Check [] Service [check [mode" [of [audio [system [AVC-LAN [diagnosis [check] (See [page [DI-809]).

CHECK:

Connection of the gateway ECU can be checked by AVC-LAN diagnosis. ("Servive check mode" of audio system)

OK: Display


G/W: OK (System is normal)
G/W: NG (Communication error)
G/W: None (Never registered)

NG

Replace the gateway ECU.

OK

2 Check wireharness



PREPARATION:

Disconnect connector "G3" of gateway ECU and "M3" of multi display.

CHECK:

- (a) Check continuity between terminals GTX+ of gateway ECU and TX3+ of multi display.
- (b) Check continuity between terminals GTX- of gateway ECU and TX3- of multi display.

<u>OK:</u>

There is a continuity in wireharness of both (a) and (b), or either (a) or (b).

HINT:

If there is OPEN in wireharness of either (a) or (b), please repair it.

NG

Repair or replace wireharness.

OK

Replace the gateway ECU.