DI2SO-02

DTC	P1633/89∏	ECU[Malfunction[ETCS[Circuit)
-----	-----------	-------------------------------

CIRCUIT DESCRIPTION

 $Refer[]\hspace{-0.1cm} \texttt{DTC} [\hspace{-0.1cm} \texttt{P11}]\hspace{-0.1cm} \texttt{29} [\hspace{-0.1cm} \texttt{Electric} [\hspace{-0.1cm} \texttt{Throttle} [\hspace{-0.1cm} \texttt{Control} [\hspace{-0.1cm} \texttt{System} [\hspace{-0.1cm} \texttt{Malfunction}) [\hspace{-0.1cm} \texttt{on} [\hspace{-0.1cm} \texttt{page} [\hspace{-0.1cm} \texttt{DI} \hspace{-0.1cm} \texttt{-50}.$

DTC[No.	DTC[Detecting[Condition	Trouble _ Area
P1633/89	Engine[ECU[malfunction	•Engine[ECU

INSPECTION PROCEDURE

HINT:

Read[freeze[frame[data[Jusing[hand-held[tester.[Because[freeze[frame[fecords[the]]]]]]] representation of the frame fram

Replace engine ECU.