SERVICE HINTS

A38 AUTO ANTENNA CONTROL RELAY AND MOTOR

3-GROUND: Always approx. 12 volts

6–GROUND : Approx. **12** volts with ignition SW at **ON** position 8–GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position

7-GROUND: Always continuity

: PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
A38		76 (LHD)	J22		78 (LHD)	R4	74 (LHD)
		90 (RHD)	J38	В	88 (RHD)	17.4	88 (RHD)
J13	Α	74 (LHD)	J45		90 (RHD)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	58 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
	58 (RHD)	Floor No.1 Wire and Driver Side J/B (Right Kick Panel)
1H	59 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
""	59 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
2E	60 (LHD)	Floor No.1 Wire and Passenger Side J/B (Right Kick Panel)
26	60 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2H	61 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)
	61 (RHD)	Cowl Wire and Passenger Side J/B (Left Kick Panel)


: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)		
ID3	108 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Blower Unit)		
IJ2	100 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)		
IL1	100 (LHD)			
IM1	110 (RHD)	Floor No.1 Wire and Cowl Wire (Right Kick Panel)		
IM3	TTO (ICITID)			


: GROUND POINTS

Code	See Page	Ground Points Location	
ВМ	102 (LHD)	Quarter Panel RH	
I DIVI	112 (RHD)	Qualter alleriti	









(Hint: See Page 7, 23, 39)

(1 mil 1 000 1 ago 1 , 20 , 0



J45

(Hint: See Page 7, 23, 39)



