## **INSTALLATION**

SA0RL-02

Installation[]s[]n[]he[]reverse[]order[]of[]removal[[See[]page[]SA-26]).

AFTER[]NSTALLATION,[]CHECK[]ABS[]SPEED[]SENSOR[]SIG[]NAL[][See[]page[]DI-210])[]AND[]FRONT WHEEL[]ALIGNMENT[[See[]page[]SA-4])