AUTOMATIC TRANSMISSION

SST (Special Service Tools)

PP087-01

	09032-00100	Oil Pan Seal Cutter
	09240-00020	Wire Gauge Set
	09350-30020	TOYOTA Automatic Transmission Tool Set
	(09350-06120)	No.2 Measure Terminal
	(09350-07020)	Oil Pump Puller
E3	(09350–0 7030)	No.1 Piston Spring Compressor
	(09350– 07040)	No.2 Piston Spring Compressor
	(09350– 07050)	No.3 Piston Spring Compressor
	(09350 –07060)	No.1 Snap Ring Expander
	(09350-07070)	No.2 Snap Ring Expander
N	(09350– 07080)	Brake Reaction Sleeve Puller
N	(09350– 07090)	Brake No.1 Piston Puller

PP

PREPARATION - AUTOMATIC TRANSMISSION

0	(09350-07110)	Oil Seal Replacer
	(09351–32140)	Oil Seal Replacer
	09350-32014	TOYOTA Automatic Transmission Tool Set
	(09351–32040)	No.1 Piston Spring Compressor
S S S S S S S S S S S S S S S S S S S	09950-60010	Replacer Set
9	(09951-00350)	Replacer 35
0011	09950-70010	Handle Set
	(09951-07100)	Handle 100

PP

PP058-01

0901712301	Deep Socket Wrench 30 mm .	
09031-00030	Pin Punch .	
09905-00013	Snap Ring Pliers .	

PREPARATION - AUTOMATIC TRANSMISSION

EQUIPMENT

PP0529-01

Feeler gauge	Check major clearance.	
Vernier calipers	Check length of 2nd coast brake piston rod.	
Dial indicator or dial indicator with magnetic base	Check piston stroke and play of the output shaft.	
Dial indicator	Check inside diameter of major bushing.	
Straight edge	Check side clearance of oil pump.	
Torque wrench		
Cylinder gauge	Check inside diameter of the transmission case rear bushing.	

PP

LUBRICANT

P05A-01

ltern	Capacity	Classification	
Dry fill	8.4 liters (8.9 US qts, 7.4 lmp qts)	ATE Type T IV or onvisolent	
Drain and refill	1.9 liters (2.0 US qts., 1.7 Imp. qts)	ATF Type T-IV or equivalent	

08826-00090	Seal Packing 1281, THREE BOND 1281 or equivalent (FIPG)	·
	(