DI86G-0

## 16. Touch switch does not function. (A/C control screen only)

INSPE	ECTION[PROCEDURE
1[]	Display[check[mode[[Touch[switch,[Touch[point[screen]].
	NG Replace the multidisplay.
ОК	
2[]	Check[]*AVC-LAN@communication@circuit**.[See@page@l-914)
	NG Replace or repair AVC-LAN circuit.
ОК	
3[]	Check[multiplex[communication[circuit[(See[page[DI-732).
	NG Replace or repair multiplex communication circuit.
ОК	
Repla	ce A/C amplifier.