DI86I-01

18. Panel Switch Does Not Function (A/C control only)

10.	
INSPE	ECTION[PROCEDURE
1[Display[check[mode[[Panel[Switch[Check[screen]].
	NG Replace the multidisplay.
ОК	
2[]	Check[]*AVC-LAN@communication@circuit**[(See@page@DI-914)[]
	NG Replace or repair AVC-LAN circuit.
ОК	
3[]	Check[multiplex[communication]circuit[(See[page[DI-732).
	NG Replace or repair multiplex communication cuit.
ОК	
Repla	ace A/C amplifier.