## **CIRCUIT INSPECTION**

DI878-01

## **Power source circuit**

## **CIRCUIT DESCRIPTION**

This circuit provides power to operate the driver door ECU.

## **WIRING DIAGRAM**



