AUTOMATIC TRANSMISSION (2JZ-GE) HOW TO PROCEED WITH TROUBLESHOOTING

DIE1K 05

When using hand-held tester, troubleshoot in accordance with the procedure on the following pages. Items inside are titles of pages in this manual, with the Vehicle[Brought[¶o[Workshop page [humber [indicated [in [the [bottom [portion. See [the [indicated pagesflordetailedexplanations. /Customer Problem Analysis P.∏∏-220 Connect[the[hand-held[tester[or[OBD[scan[tool[to]DLC3. Iffthefdisplay[\$hows[]UNABLE[TO[CONNECT[TO[VEHICLE]]]when[you]have[connected[the OBD[\$can[lool/hand-held[tester, [inspect[DLC3[P.[DI-221] //Check[DTC[and[Freeze[Frame[Data[Precheck] Record[or[Print[DTC[and[Freeze[Frame[Data[P.[DI-221 4 //Clear DTC and Freeze Frame Data P. DI-221 5// Visual Inspection // 6 / Setting The Check Mode Diagnosis P. DI-221 Symptom does not occur // Symptom[\$imulation 7 Problem Symptom Confirmation P.∏N-20 Symptom occurs DTC[Check Basic Inspection // NG P[DI-221 OK 10 DTC|Chart // Mechanical System Test P.∏∏-221 OK NG 13 Manual Shifting Test P.[D[]-221 14 Problem [\$ymptoms [Table - [P. [DI] - 240] NG Chapter 1 Chapter 2 Chapter[3] OK OK (Electronic) (On-Vehicle) (Off-Vehicle) P.∏∏-240 P.⊓. 240 NG NG 16 // Parts Inspection Stop[Light[Switch[Signal[Circuit[Check] Circuit • Transmission Shift Switch Circuit Check Inspection P. DII-266 to DI-272

Repair

Confirmation Test

When not using hand-held tester, troubleshoot in accordance with the procedure on the following pages.

