CIRCUIT INSPECTION

DI1AS-23

DTC	B2795/99	Unmatched Key Code
-----	----------	--------------------

This DTC is output when an unregistered key is inserted. When this DTC is output, delete DTC and insert the key that a customer keeps to check that B2795 is output.

When a key that outputs B2795 is found, register this key. when B2795 is not output, there is a possibility that the unregistered key has been inserted before. (Engine and ECT ECU is normal.) Inquire a customer the condition of using the system to find the cause of the trouble.

(Example: Another key has been inserted, etc..)