nibly

WANNA BITE?

Cypress Vending Corp.

SMART, BOLD, DIGITAL VENDING

QUICK START SUPPLEMENTARY DOCUMENT

REMOVING NIBLY SNACKS MACHINE

Unpacking Instructions

YOUR NIBLY SNACKS VENDING MACHINE IS FITTED WITH SPECIAL PALLETS AT OUR SHIPPING WAREHOUSE.

These pallets protect the machine from accidental damage that might occur during freight shipment.

TOOLS REQUIRED:

- Screwdriver with Phillips head. A drill or electric screwdriver is recommended
- Hammer or pry bar
- Utility knife or scissors to cut ties
- Gloves

PLEASE NOTE: The machines are heavy and this procedures requires 3 people to do safely. If you have any doubt about your ability to do this safely **STOP** and hire a professional insured mover.

REMOVING NIBLY SNACKS MACHINE FROM THE SPECIAL PALLET

Your Nibly Snacks machine can be stored on its pallet until they are ready to be located. Many operators choose to leave their machines on the pallets until they are delivered to their locations where the pallets can be removed outside of the location or at their final destination. The machines will be easier to move on the pallet because it was built to accommodate a full size pallet jack (pump jack).





STEP 1. Remove the screws that secure the front panel of the pallet to the frame. We recommend using an electric screwdriver or drill with a Phillips bit.



Remove the 4 screws from the front panel.

REMOVING NIBLY SNACKS MACHINE FROM THE SPECIAL PALLET, CONTINUED.

STEP 2. Remove the screws that secure the 2 x 2 hold-down dowels. These keep the feet securely mounted to the pallet. There are two screws on each side of the pallet holding the dowels in place. Remove front panel.



Remove the screws for the hold-down dowels.



Pallet with front panel removed.

STEP 3. Unscrew the corner blocks on both sides of the open side of the pallet. There are two screws on each side.



Unscrew the corner blocks .

REMOVING NIBLY SNACKS MACHINE FROM THE SPECIAL PALLET, CONTINUED.

STEP 4. Note: You only need to remove your machine from the pallet when it has reached the location where it will be in operation. You can install your Nayax devices and perform other setup procedures with the front panel of the machine removed but the machine still sitting on the pallet at your staging location before moving the machine to the location.

To remove the machine from the pallet: slide the machine along the 2 x 6 boards toward the front of the pallet and then place two front feet of the machine on the floor. Tilt the machine forward and pull the pallet out from behind. Make sure the machine is secured from the front. With the weight of the machine on the front two feet, the pallet is easily removed.



Secure the machine from the front. Remove pallet.



Machine on pallet.

REMOVING NIBLY SNACKS MACHINE FROM THE SPECIAL PALLET, CONTINUED.



Cut tie-down straps.

STEP 5. Remove the cardboard cover by cutting the nylon straps and then the plastic inner covering will slide up and off the machine.



OPENING THE MACHINE DOOR AND REMOVE PARTS

STEP 6. Once you have removed the machine from the pallet and removed all external packaging, you will want to open the door of the machine and remove the air diverter. The key for your machine will be in the zip-locked bag located in the drop box behind the “Push” door. The trays have been secured by a transport tray lock, preventing the trays from sliding forward when the machine is tilted. See the Quickstart Guide in the Nibly Snacks Operations manual for instructions on installing the air diverter and removing the tray transport lock.