

- G 1 Airbag Sensor Assembly
- G 2 Mayday Battery
- G 3 Combination Meter Assembly
- G 4 Turn Signal Flasher Assembly
- G 5 VSC Off Switch
- G 6 Outer Mirror Switch Assembly
- G 8 Light Control Rheostat
- G 9 Center Differential Lock Switch
- G 12 A/C Amplifier Assembly
- G 13 A/C Amplifier Assembly
- G 14 Front Blower with Fan Motor Sub-Assembly
- G 15 Intake Air Temperature Sensor
- G 16 Glove Box Light
- G 17 Interior Foot Light RH
- G 18 Interior Foot Light LH
- G 19 Lower No. 1 Instrument Panel Airbag Assembly
- G 20 Lower No. 2 Instrument Panel Airbag Assembly
- G 21 Steering Sensor
- G 22 No. 1 Clearance Warning Buzzer
- G 23 Steering Lock Actuator Assembly
- G 24 Engine Switch
- G 25 ID Code Box
- G 26 Certification ECU Assembly
- G 27 Certification ECU Assembly
- G 28 Spiral Cable Sub-Assembly
- G 29 Spiral Cable Sub-Assembly
- G 30 Steering Wheel Heater Control Assembly
- G 31 Headlight Dimmer Switch Assembly
- G 32 Shift Lock Control ECU Sub-Assembly
- G 33 Multiplex Tilt & Telescopic ECU
- G 34 Seat Belt Control ECU
- G 35 Seat Belt Control ECU
- G 36 Transmission Control Switch
- G 37 DLC3
- G 38 Power Management Control ECU
- G 39 Power Management Control ECU
- G 40 Yaw Rate Sensor Assembly
- G 41 Four Wheel Drive Control ECU
- G 42 Four Wheel Drive Control ECU
- G 43 Driving Support ECU Assembly
- G 44 ECM
- G 45 ECM
- G 46 Main Body ECU









