

- P 1 Front Side Step Light RH
- P 2 Front Side Step Light LH
- P 3 Rear Side Step Light RH
- P 4 Rear Side Step Light LH
- U 1 Rear No. 1 Ultrasonic Sensor Center RH
- U 2 Rear No. 1 Ultrasonic Sensor RH
- U 3 Back-Up Light Assembly RH
- U 4 Back-Up Light Assembly RH
- V 1 Rear No. 1 Ultrasonic Sensor Center LH
- V 2 Rear No. 1 Ultrasonic Sensor LH
- V 3 Back-Up Light Assembly LH
- V 4 Back-Up Light Assembly LH
- W 1 Vanity Light Assembly LH
- W 2 Sliding Roof Control ECU
- W 3 Vanity Light Assembly RH
- W 4 Inner Rear View Mirror Assembly
- W 6 Rain Sensor
- W 7 Map Light Assembly
- W 8 Visor Assembly LH
- W 9 Visor Assembly RH
- W 10 No. 1 Room Light Assembly LH
- W 11 No. 1 Room Light Assembly RH
- W 13 No. 2 Room Light Assembly LH
- W 14 No. 2 Room Light Assembly RH
- W 15 Inner Rear View Mirror Assembly
- X 1 Rear Television Camera Assembly
- X 2 Back Door Lock Assembly
- X 3 Glass Hatch Opener Switch Assembly
- X 4 Back Window Lock Assembly
- X 6 Luggage Electrical Key Switch
- Y 1 Rear Wiper Motor Assembly
- Y 2 Rear Window Defogger (Back Door Glass)
- Z 1 Center Stop Light Assembly
- j 1 Front Door Inside Handle Illumination Light Assembly RH
- k 1 Front Door Inside Handle Illumination Light Assembly LH
- c 2 Seat Memory Switch
- m 1 Rear Door Courtesy Light Assembly RH
- m 2 Rear Door Courtesy Light Assembly LH
- m 3 Rear Door Inside Handle Illumination Light Assembly RH
- m 4 Rear Door Inside Handle Illumination Light Assembly LH
- q 1 Rear Speed Sensor RH
- 2 Rear Speed Sensor LH
- z 2 Outer Mirror Control ECU Assembly RH, Outer Rear View Mirror Assembly RH
- z 3 Outer Mirror Control ECU Assembly LH , Outer Rear View Mirror Assembly LH



