## 5. PROCEDURES NECESSARY WHEN CABLE IS DISCONNECTED/RECONNECTED TO BATTERY TERMINAL

## (a) THE WORK LIST

(1) Each inspection procedure refers to the LEXUS Repair Manual.

Necessary Procedure	Effect or Inoperative Function when Necessary Procedure is not Performed
Adjust parking assist monitor system	Calibration

## **NOTICE:**

- After the battery is reconnected, be sure to wait 10 seconds or more before attempting to start the engine. The engine may not start immediately after the battery is reconnected.
- w/ Navigation System (for HDD):
   After the engine switch is turned off, the HDD navigation system requires approximately a minute to record various types of memory and settings. As a result, after turning the engine switch off, wait a minute or more before disconnecting the cable from the negative (–) battery terminal.