
QUARTER PANEL (ASSY)




Symbol meaning


▲ : Remove Weld Points 🖺 : Cut with Disc Sander etc.

4 : Cut Location for Supply Parts


F43271B


[LH]





[RH]





F43272


Symbol meaning


Spot Weld : Plug Weld : Butt Weld

: Body Sealer

F43273B

INSTALLATION





mm (in.)

F43273

INSTALLATION POINT

- 1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- 2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- 3 Before installing a new part, apply body sealer. HINT:


Apply body sealer evenly about 5 mm (0.20 in.) from the flange, avoiding any oozing. Apply body sealer evenly, about 3-4 mm (0.12 - 0.16 in.) in diameter.


Symbol meaning

• : Spot Weld : Plug Weld : Butt Weld


: Body Sealer


F43273B





[RH]





F43274

INSTALLATION POINT

- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the
- 2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- 3 After welding, apply the foamed sealing material to the corresponding parts. (See the paint coating)
- After welding, apply body sealer to the corresponding parts. (See the paint coating)
- 4 5 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.