


## **LEXUS GX460**



C				
		1.35 to 1.45 (1.43 to 1.53, 1.18 to 1.27)	<b>2.65 to 2.75</b> (2.80 to 2.91, 2.33 to 2.42)	
Liter (US qts, Imp. qts)		Toyota Genuine Differential gear oil LT 75W-85 API GL-5 or equivalent		
N*m (kgf*cm, ft.*lbf)		<b>65</b> (660, 48)	<b>49</b> (500, 36)	
		URJ		
		<b>112</b> (1142, 83)		
N*m (kgf*cm, ft.*lbf)		URJ		
		<b>30</b> (1.18)		
	mm (in.)			
BA C	Α	<b>0°9' +/-45'</b> (0.15° +/-0.75°)		
	В	<b>12°3' +/-45'</b> (12.05° +/-0.75°)		
₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩ ₩	С	<b>3°10' +/-45'</b> (3.17° +/-0.75°)		
	D	<b>36°6'</b> (36.10°)		
E H Front	E+F	0°4' +/-0°10' (0.07° +/-0.16°)		
	G-H mm (in.)	2.0 +/-2 (0.08 +/-0.08)*2 1.9 +/-2 (0.07 +/-0.08)*3		
	URJ150L-GKTZKC	<b>220</b> (2.2, 32)		
	URJ150L-GKTZKV	<b>200</b> (2.0, 29)		
<b>kPa</b> (kgf/cm², psi)	URJ150L-GKTZKW			

<sup>\*1:</sup> When the brake pedal is depressed with the force of 490 N (50 kgf, 110.2 lbf) while the engine is running.

<sup>\*2:</sup> except G. C. C. \*3: for G. C. C.

(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c			
*1		Parking Assist Monitor System	
		1.25 to 1.29	
20°C (68°F)		1UR-FE	
	cc (cu. in.)	<b>4608</b> (281.2)	
		-	
A	DENSO	SK20HR11	
	NGK	-	
	A mm (in.)	<b>1.0 to 1.1</b> (0.0394 to 0.0433)	
[DLC3 terminals 13 (TC) - 4 (CG) connected]		8 to 12° [Transmission in neutral and A/C switch OFF]	
mm (in.)	¥¥(	-	
		-	
[DLC3 Terminal 9 (TAC) Connected]		<b>550 to 780</b> [Transmission in neutral and A/C switch OFF]	

(T)		<b>1300</b> (13.3, 189)	
		<b>1000</b> (10.2, 145)	
kPa (kgf/cm², psi)		<b>100</b> (1.0, 15)	
		<b>70</b> (0.7, 10.1)	
kPa (kgf/cm², psi)	2500 rpm	<b>1 220</b> (2.2, 32)	
1.1.1		1UR-FE	
A		<b>7.4</b> (7.8, 6.5)	
		<b>7.8</b> (8.2, 6.9)	
		20W-50 15W-40	API grade SL or SM multigrade engine oil
Liter (US qts, Imp. qts)		10W-30 5W-30 5W-20 0W-20	API grade SL "Energy-Conserving", SM "Energy-Conserving" or ILSAC*2 multigrade engine oil
N*m (kgf*cm, ft.*lbf)	<b>A</b>	<b>40</b> (408, 30)	
Liter (US qts, Imp. qts)		<b>15.4</b> (16.3, 13.6)	

<sup>\*1:</sup> The initialization is required. Refer to the repair manual for the initialization procedures. \*2 ILSAC: International Standardization and Approval Committee

## **TOYOTA MOTOR CORPORATION Technical Service Division**