

- C 85 Fuel Temperature Sensor
- C 86 Electric EGR Control Valve Sensor
- C 87 Nozzle Vane Position Sensor
- C 88 Injector Driver
- C 89 Injector Driver
- C 94 Viscous with Magnet Clutch Heater Assembly
- C 95 Starter Assembly
- C 96 Engine Oil Pressure Switch Assembly
- C 97 Generator Assembly
- C 98 Glow Plug Assembly
- C 99 Injector Driver
- C 115 Fuel Injector Assembly No. 1
- C 116 Fuel Injector Assembly No. 2
- C 117 Fuel Injector Assembly No. 3
- C 118 Fuel Injector Assembly No. 4
- C 119 Crank Position Sensor
- C 120 No. 2 EGR Valve Assembly
- C 121 Injector Driver
- C 122 Injector Driver
- C 123 Oil Pressure Sender Gage Assembly
- C 124 Injector Driver
- C 125 Injector Driver
- C 126 Exhaust Fuel Addition Injector Assembly
- C 127 Electric EGR Control Valve Assembly
- C 128 VSV (for EGR Cooler)
- C 129 Differential Pressure Sensor Assembly
- C 130 Oil Pressure Switching Valve Assembly
- C 131 Air Fuel Ratio Sensor
- C 132 Glow Plug Assembly
- C 133 No. 2 Exhaust Gas Temperature Sensor
- C 134 No. 3 Exhaust Gas Temperature Sensor
- C 135 No. 1 Exhaust Gas Temperature Sensor
- D 5 Starter Assembly
- D 6 Starter Assembly
- p 1 Front Speed Sensor RH
- p 2 Front Speed Sensor LH



