



G8Turn Signal Flasher Assembly വ 12 **(B)** 11 (B) 10 **(B)** 9 (B G89(A), G90(B) Junction Connector 10 (A) വ വ 20 (A 19 (A 17 GR3 18 GR3 G6(A) Combination Meter Assembly Turn RH Turn LH R28 Junction Connector 20 21 21 **(**A) BR 5 (*15) 5 (*16) 6* 55 (3A വ R22 Rear Combination Light Assembly LH Q31 Rear Combination Light Assembly RH R21 Rear Combination Light Assembly RH G92(A), G143(B) Junction Connector TRN TRN TRN 6 (A) (*15) 6 (B) (*16) 25 (3B) 틸(3 9 틸(9 BR W-B W-B 70 (4A G128(C), G129(D) Junction Connector W-B W-B W-B 10 (4B) W-B R (*10) R28 Junction Connector * 7 : w/ Parking Assist (TOYOTA Parking Assist-Sensor) (4 Sensor Type) * 8 : w/o Parking Assist W-B BR (TOYOTA Parking Assist-Sensor) (4 Sensor Type) * 9 : 5-Door *10 : 3-Door *11:1GR-FE (*11) (*12) BR BR BR G106 R31 *12 : 2TR-FE (*13) Junction Connector Junction Connector *13 : 1KD-FTV *14 : 5L-E *15 : Before Oct. 2010 Production *16 : From Oct. 2010 Production









