C2.2 Additional channels defined by ACE

The following subsections introduce the ACE snoop channels:

- *Snoop address channel (AC) signals*
- *Snoop response channel (CR) signals*
- *Snoop data channel (CD) signals* on page C2-154.

C2.2.1 Snoop address channel (AC) signals

Table C2-4 shows the signals on the snoop address channel. See *Snoop address channel signaling* on page C3-173.

Table C2-4 Snoop address channel signals

Signal	Source	Description
ACVALID	Interconnect	Snoop address valid. This signal indicates that the snoop address and control information is valid.
ACREADY	Master	Snoop address ready. This signal indicates that the snoop address and control information can be accepted in the current cycle.
ACADDR[ac-1:0][a]	Interconnect	Snoop address. This signal indicates the address of a snoop transaction. The snoop address width must match the width of the read and write address buses.
ACSNOOP[3:0]	Interconnect	Snoop transaction type. This signal indicates the transaction type of the snoop transaction.
ACPROT[2:0]	Interconnect	Snoop protection type. This signal indicates the security level of the snoop transaction. The ACE specification only assigns meaning to **ACPROT[1]**.

a. ac is the width of the snoop address bus.

C2.2.2 Snoop response channel (CR) signals

Table C2-5 shows the signals on the snoop response channel. See *Snoop response channel signaling* on page C3-176.

Table C2-5 Snoop response channel signals

Signal	Source	Description
CRVALID	Master	Snoop response valid. This signal indicates that the snoop response is valid.
CRREADY	Interconnect	Snoop response ready. This signal indicates that the snoop response can be accepted in the current cycle.
CRRESP[4:0]	Master	Snoop response. This signal indicates the response to a snoop transaction and how it completes.

Copyright © 2003, 2004, 2010, 2011 ARM. All rights reserved.
Non-Confidential

C2.2.3 Snoop data channel (CD) signals

Table C2-6 shows the signals on the snoop data channel. See *Snoop data channel signaling* on page C3-180.

Table C2-6 Snoop data channel signals

Signal	Source	Description
CDVALID	Master	Snoop data valid. This signal indicates that the snoop data is valid.
CDREADY	Interconnect	Snoop data ready. This signal indicates that the snoop data can be accepted in the current cycle.
CDDATA[cd-1:0][a]	Master	Snoop data. Transfers data from a snooped master.
CDLAST	Master	This signal indicates the last data transfer of a snoop transaction.

a. cd is the width of the snoop data bus.

Copyright © 2003, 2004, 2010, 2011 ARM. All rights reserved.
Non-Confidential