Arduino Setop:

Plug in Arduino & Nait For drivers

Run Arduino app [ [ ]

"Tools" > "Bort" > "OM# (Arduino)"

"File" > "Examples" > "Basics" -> "Blink"

To bad the program & run it