

EDGE INDUSTRIAL SYSTEMS - TECHNICAL SPECIFICATION

Equipment Type: Heavy Duty Process Pump Overhaul Guide

Document Reference: EIS-MAN-2026-V1

Section 1: Disassembly & Rotor Inspection

- 1.1 Drain casing and disconnect all auxiliary seal flush and cooling lines.
- 1.2 Mount dial test indicators (DTI) on both driving and non-driving ends.
- 1.3 Record total axial float before loosening bearing locknuts (nominal: 0.12 - 0.18 mm).
- 1.4 Carefully hoist top casing half using certified spreader beam and rated shackles.

Section 2: Mechanical Seal Installation & Alignment

- 2.1 Clean stuffing box face and verify perpendicularity within 0.05 mm TIR.
- 2.2 Slide mechanical seal cartridge over shaft sleeve using soapy water lubricant.
- 2.3 Tighten gland retaining nuts in cross pattern to torque of 45 Nm.
- 2.4 Perform laser shaft alignment: angular tolerance 0.05 mm/100mm, parallel offset 0.03 mm.

- 2.5 Rotate pump shaft by hand to confirm smooth, binding-free rotation.