

BlazeLight Camp Stove - Manual

1. Unfold the three support legs until they lock into place.
2. Thread the fuel canister into the stove's regulator valve until snug.
3. Open the fuel valve slightly and press the piezo igniter button to light the burner.
4. Adjust the control dial to set flame height.
5. After use, close the fuel valve fully and allow the stove to cool before disassembly.

Boil time: approximately 3.5 minutes per liter at sea level.