

BlazeLight Camp Stove - Troubleshooting: Won't Ignite

- Confirm the fuel canister is not empty by shaking it gently.
- Check that the fuel valve is open before pressing the igniter.
- Inspect the piezo igniter electrode for soot buildup; clean gently with a dry cloth.
- If the piezo igniter fails, use a long-reach lighter as a backup ignition source.
- In cold temperatures below freezing, warm the fuel canister in a jacket pocket first.