



Web Dashboard — User Guide



Gateway for the Hoymiles HMS-800W-2T solar inverter

Firmware **v0.5.2** and later · Document date **2026-08-11**
github.com/danielguedel/HMS-GW-S3

Contents

1. Introduction	4
2. Getting Started	4
3. The Dashboard Tab	5
4. The Relay / IO Tab	0
5. The Config Tab	0
6. The System Tab	0
7. Remote Access (Mobile App)	0
8. Troubleshooting	0
9. Appendix: Status Colour Legend	0

1. Introduction

The HMS-GW-S3 gateway reads live data from your Hoymiles HMS-800W-2T solar inverter and makes it available through a built-in **web dashboard** — no app, no cloud account, no installation required. Just open a browser and point it at the gateway's IP address.

This guide covers everything you can do from that dashboard: monitoring live solar output, controlling the relay and auxiliary IOs, changing WiFi/MQTT/network settings, and updating the firmware.

ALSO AVAILABLE

A companion Progressive Web App for viewing and controlling the gateway from outside your home network is covered briefly in §7 and described in full in the project's README.

What you need

- A device with a modern web browser (phone, tablet, laptop, desktop — any OS)
- The gateway connected to your WiFi network (see §2 if this is a first-time setup)
- The gateway's IP address, or its factory-default access point if it isn't on your network yet

2. Getting Started

2.1 First connection (factory-new device)

Out of the box, the gateway cannot yet know your home WiFi credentials, so it opens its own temporary access point:

- 1 On your phone or laptop, open the WiFi settings and connect to the network named `HMS-GW-S3`. No password is required.
- 2 Open a browser and go to `http://192.168.4.1`.
- 3 The dashboard loads. Switch to the **Config** tab (see §5) and enter your home WiFi network name (SSID) and password under the "WiFi" section.
- 4 Click **Save**. The gateway restarts and connects to your home network.

NOTE

Once connected to your home network, the temporary `HMS-GW-S3` access point disappears — you'll need the gateway's new IP address to reach it again (see below).

2.2 Finding the gateway on your network

After the WiFi setup above, the gateway gets its address from your router (DHCP) unless you configured a static IP. The most reliable way to find it:

- Open your router's admin page and look at the list of connected devices for one named `HMS-GW-S3` (or similar).
- Alternatively, check the gateway's status LED behaviour or serial console output if you have access to it (see the project's technical specification for LED colour meanings).

There is no `.local` hostname — the gateway must be reached by its numeric IP address (e.g. `http://192.168.1.42`).

2.3 Bookmark it

Once you know the address, bookmark it in your browser for quick access later. If you later assign the gateway a static IP (Config tab → Network), that address won't change again.