

2785.79_H02

LIST OF FAULTS CMC4+20.50

CODE	DISPLAY	OUT AV	NEMONIC	MEANING CMC4+20.50	SUB-CODE
0	NO	NO	NORMAL	Normal operation	
1	*0	NO	NO_ABRE_FPAF	Front door open end-stop switch does not open	
2	*0	NO	NO_ABRE_FPAT	Rear door open end-stop switch does not open	
3	*0	NO	NO_CIERRA_FPAF	Front door open end-stop switch does not close	
4	*0	NO	NO_CIERRA_FPAT	Rear door open end-stop switch does not close	
5	*0	NO	NO_ABRE_FPCF	Front door closed end-stop switch does not open	
6	*0	NO	NO_ABRE_FPCT	Rear door closed end-stop switch does not open	
7	*0	NO	NO_CIERRA_FPCF	Front door closed end-stop switch does not close	
8	*0	NO	NO_CIERRA_FPCT	Rear door closed end-stop switch does not close	
9	*0	NO	AP_FRON_ACT	Front door open button operated excessively	
10	*0	NO	AP TRAS_ACT	Front door open button operated excessively	
11	*0	NO	CAP_FRONT_ACT	Front door edge capacitive detector activated	
12	*0	NO	CAP TRAS_ACT	Rear door edge capacitive detector activated	
13	*0	NO	FOT_FRONT_ACT	Front photocell activated	
14	*0	NO	FOT TRAS_ACT	Rear photocell activated	
15	*0	NO	BORDE_FRONT_ACT	Front door edge safety detector activated	
16	*0	NO	BORDE TRAS_ACT	Rear door edge safety detector activated	
17	*5	NO	NO_ABRE_41	Interlock chain does not open on the open command	
18	*5	NO	NO_ABRE_40	Presence circuit does not open on the open command	
19	*9	NO	FALLO_E2PROM	Fault detected in EPROM memory	
20	*7	NO	NO_HAY_40	No signal detected from the presence circuit	
21	*7	NO	NO_HAY_41	No signal detected from the interlock chain	
22	*A	YES	FALLO_SR	Fault detected in SR module	
23	NO	NO	PRIORIDAD_CABINA	Car preference connected	
24	NO	NO	FUNCIÓN_BOMBEROS	Fireman's service switch activated	
25	NO	NO	FUERA_SERVICIO	Out-of-service switch activated	
26	*0	NO	EARTHQUAKE_ON	Activation of seismic sensor detected	
27	NO	NO	FALLO_COM_POSICION	Position communication error	
28	*9	NO	APER_SSEG_500	Series circuit opening <500mseg	
29	*4	NO	APER_PTARUN_200	Door opening while moving <200mseg	
30	NO	NO	AVISO_MANTENIMIENTO_CORREAS	In belt-driven lifts, maintenance warnings after pre-set number of journeys.	
31	SI	YES	APER_PISADERA_CABINA	In lifts with no car doors, opening of the car sill contact	
32	NO	NO	EXCESO_CARGA	Overload sensor activated	
33	NO	NO	EXCESO_CARGA_80	Load >80% sensor activated	
34	NO	NO	FALLO_MPLEX	Communications fault in the multiplex group	
35	NO	NO	CORRIENTE_EMERGENCIA	Emergency current function activated	
36	NO	NO	EXCESO_ANS	Expected non-simultaneous start time exceeded	
37	NO	NO	ACT_SENSOR_FUEGO	Fire sensor activated	
38	NO	NO	FALLO_MX_FS	Multiplex weighting error, front door up calls	
39	NO	NO	FALLO_MX_FB	Multiplex weighting error, front door down calls	
40	NO	NO	FALLO_MX_TS	Multiplex weighting error, rear door up calls	
41	NO	NO	FALLO_MX_TB	Multiplex weighting error, rear door down calls	
42	NO	NO	FALLO_SLAVES	Multiplex communications error, fault in parameter "mult-number".	
43	NO	NO	FALLO_PROTEC_SALIDAS	Short-circuit fault in a protected output of the UCM2.1. (See "fault sub-codes" for more information).	YES
44	NO	NO	POWER_FAIL	Power failure	
45	NO	NO	FALLO_24V	24V failure	
46	NO	NO	STS_SHABBAT	Indicates that operation is in the SHABBAT mode	
47	*8	NO	FALLO_EQUIPO_EMERG	Emergency equipment fault signal connected in the car (EAR) activated	
48	*6	YES	ERROR_CONTAJE	Fault in landing magnet count (copied from the lift shaft)	
49	*0	YES	OVER_CONEX	Connections/hour limit exceeded	
50	*7	YES	NO_CIERRA_41	No interlock signal when trying to close the door	
51	*7	YES	NO_CIERRA_40	No presence signal when trying to close the door	
52	*7	YES	OVERT_DOOR	Door close attempts limit "close_attempts" exceeded.	
53	*0	YES	NO_NEXT_START	"NOSTART" X91.2 or X899.6 activated	
54	*2	YES	AMBOS_CM_ACC	Both speed changes activated	
55	*8	YES	PMS_SIN_PANT	Ascending stop activated without landing magnet (1V)	
56	*8	YES	PMB_SIN_PANT	Descending stop activated without landing magnet (1V)	

57	*9	YES	APER_SERIE_SEG	Safety circuit opened while moving	
58	*4	YES	APER_S40_MARCHA	Presence circuit opened while moving	
59	*4	YES	APER_S41_MARCHA	Interlock chain opened while moving	
60	*9	YES	INCONGRUENCIA	Erroneous variables detected	
61	*6	YES	CMS_ERROR	Incorrect activation of speed change signal B323 when ascending	
62	*6	YES	CMB_ERROR	Incorrect activation of speed change signal B322 when descending	
63	*9	YES	APER_SEG_CMS	Opening with ascending speed change signal B323	
64	*9	YES	APER_SEG_CMB	Opening with descending speed change signal B322	
65	*9	YES	PROGRAM_ERROR	Every time that the control unit resets due to detection of an operating anomaly. Function implemented in versions UCM2 v01.06.15 and later.	
66	*3	YES	SITUAC_INSPEC	Inspection switch connected	
67	*3	YES	SITUAC_RAPPEL	Recuperation control unit connected	
68	NO	NO	SITUACIÓN_CORREC	Lift in correction phase	
69	*0	YES	DETECT_LOAD.100	Overload activated	
70	*8	YES	NO_COMUNIC_CAB	Fault in communications with the car	
71	*0	YES	DETECT_SOBREC_DIF	Differential overload activated	
72	*A	YES	NO_AREA_RENIV	No area signal	
73	*0	YES	CAPF_ACT_30S	Front door edge capacitive detector activated for 30s.	
74	*9	YES	ON_MODOTEST	UCM2 board test mode activated	
75	*9	YES	NO_COPYE2P	Error copying parameters from the EEPROM	
76	*3	YES	APER_PTA_V0	Passage door opened with no power to control unit, reset by operating and releasing Emergency Switch on control panel	
77	NO	NO	CORTO_UCC	Short-circuit in car circuit board UCC2. This can also be tripped by excess power consumption.	
78	*3	YES	APER_PTA_V1	Passage door opened with power to control unit.	
79	*A		NO_VEL_0_MTR		
80	*0	YES	CAPT_ACT_30S	Rear door edge capacitive detector activated for 30s.	
81	*0	YES	FOTF_ACT_30S	Front photocell activated during 30s.	
82	*0	YES	FOTT_ACT_30S	Rear photocell activated during 30s.	
83	*0	YES	BORF_ACT_30S	Front safety edge activated for 30s.	
84	*0	YES	BORT_ACT_30S	Rear safety edge activated for 30s.	
85	*H	YES	NO_UCPS_TRASERO	Error during teach-in, a rear floor circuit board was not detected. (See "fault sub-codes" for more information).	YES
86	*H	YES	NO_UCPS_FRONTAL	Error during teach-in, a front floor circuit board was not detected. (See "fault sub-codes" for more information).	YES
87	*H	YES	MAS_UCPS_FRONTAL	Error during teach-in, more floor circuit boards detected than programmed (front).	YES
88	*H	YES	MAS_UCPS_TRASERO	Error during teach-in, more floor circuit boards detected than programmed (rear).	YES
89		NO	OBS_FALLO_NO_REGISTRADO	Unassigned faults	
90	*C	YES	LOST_UCC	Communications with car lost	
91	*C	YES	NO_INIT_UCC_FRONT	Car front board initialisation error	
92		YES	OBS_NO_INIT_UCC_TRAS		
93	*0	YES	SOBRETEMP_CTOMAQ	Machine room high temperature fault	
94	*0	YES	SOBRETEMP_PTC	PTC high temperature fault	
95	*1	YES	NO_CAE_K852	Run contactor K852 not opening	
96	*1	YES	NO_ENTRA_K852	Run contactor K852 not closing	
97	*1	YES	NO_CAE_K815	Continuous brake contactor K815 not opening	
98	*1	YES	NO_ENTRA_K815	Continuous brake contactor K815 not closing	
99	*1	YES	NO_CAE_K817	Alternative brake contactor K817 not opening	
100	*1	YES	NO_ENTRA_K817	Alternative brake contactor K817 not closing	
101	*1	YES	FALLO_CANCPI	CAN communications fault between control unit and frequency converter	
102	*1	YES	FALLO_SECCPI	CPI sequence error during starting, braking or changing speed. (CPI-CAN)	
103	*1	YES	FALLO_HNDCHKM16R8	Communications fault between UCM2 and UCV	
104	*1	YES	NO_ENTRA_BRK1	Brake contacts supervision, contactor BRK1 not closing (Frequency converter CAN)	
105	*1	YES	NO_CAE_BRK1	Brake contacts supervision, contactor BRK1 not opening (Frequency converter CAN)	
106	*1	YES	NO_ENTRA_BRK2	Brake contacts supervision, contactor BRK2 not closing (Frequency converter CAN)	
107	*1	YES	NO_CAE_BRK2	Brake contacts supervision, contactor BRK2 not opening (Frequency converter CAN)	
108	*1	YES	FALLO_INITCPI	Initialisation error between control unit and frequency converter.	
109	NO	NO	SHAFT_FUME_SENSOR_ON	Lift-shaft smoke detector activated.	
110	*A	YES	FALLO_CMI_A3	Fault in uncontrolled movement monitoring system	
111	*8	YES	INCOHERENCIA_CONTAJE	Fault in end-point bistable B322 or B323	
112	NO	NO	INUNDACION_SENSOR_ON	Flooding buoy sensor activated	
113	*A	YES	ERROR_PARAM_CMI_A3	Error in control parameter ControlMI_A3	
114	*0	YES	NIVEL_BAJO_ACEITE	Low oil level detected in a hydraulic lift	
115	NO	NO	LUZ_CABINA_SENSOR_ON	Car light fault detected	

116	*0	YES	PARADA_TELESERVICIO	Remote service stop command received	
117	NO	NO	BLOQUEO_EVACUACION	After an automatic Fire Service evacuation as per parameter "ResetFireService", the lift is blocked until it is reset.	
118	*3	YES	BLOQUEO_A3_FUERA_SR	An output has been detected from the uncontrolled-area zone.	
119	*3	YES	FALLO_CORRECCION	Start-up sequence cannot be initiated in correction phase	
120	*1	YES	BLOQUEO_MSW__FRENO	Operation blocked due to brake microswitch failure	
121	*A	YES	BLOQUEO_SR	Operation blocked due to pre-opening SR module failure	
122	*1	YES	FALLO_ABRIR_FRENO	The brake does not release in the start-up sequence	
123	NO	NO	FALLO_SERIES_SECUENCIA	The interlock or presence circuit opened during the start or stop sequence	
124	*1	YES	ERROR_ICON_BUCHER	Error in a group of Bucher ICON hydraulic lifts	
125	NO	NO	EVACUACION_INCENDIO	Activate evacuation according to standard EN81-73 by a programmable input	
126	*9	YES	NO_TMAXNUDGE	"tmaxnudge" parameter programmed nudging time out of range.	
127	*9	YES	NO_PLT_CORTAS	"PltCortas" parameter, zone of short floors badly defined.	
128	*0	YES	IMMEDIATE_STOP	Immediate stop, input X90.2 of UBA2 deactivated	
129	*8	YES	NO_PULSOS_PANT	No pulses received from landing magnet	
130	*8	YES	EXCESO_PEQUEÑA	Maximum programmed slow time exceeded	
131	*1	YES	NO_ENTRA_HCONT	High-speed contactor not closing	
132	*1	YES	NO_CAE_HCONT	High-speed contactor not opening	
133	*1	YES	NO_ENTRA_LCONT	Low-speed contactor not closing	
134	*1	YES	NO_CAE_LCONT	Low-speed contactor not opening	
135	*1	YES	NO_ENTRA_UCONT	Ascend contactor not closing	
136	*1	YES	NO_CAE_UCONT	Ascend contactor not opening	
137	*1	YES	NO_ENTRA_DCONT	Descend contactor not closing	
138	*1	YES	NO_CAE_DCONT	Descend contactor not opening	
139	*1	YES	NO_CAE_UDCONT	Direction contactor not opening	
140	*8	YES	NO_PROX_PAR	*****	
141	*9	YES	NO_MOTORCODE	*****	
142	*2	YES	INVERSION_FASES	Inverted movement direction detected	
143	*9	YES	FALLO_GRAB_EEPROM	Error writing parameters to the EEPROM	
144	*8	YES	ERROR_COLC_PANT	Error in landing magnet placements	
145	*8	YES	NO_SALE_PANT	Start-up order issued and does not leave landing magnet	
146	*9	YES	FALLO_RAM	RAM read/write error	
147	*9	YES	FALLO_PARAM_EPROM	Parameter range error (see "fault sub-codes" for more information).	YES
148	*9	YES	NO_MAXT_DOOR	*****	
149	*9	YES	NO_CONEX_HORA	*****	
150	*9	YES	NO_RESERVA_CONEX	*****	
151	*9	YES	NO_MAXT_GRANDE	*****	
152	*9	YES	NO_MAXT_PEQUEÑA	*****	
153	*9	YES	NO_MAXT_RENIVEL	*****	
154	*9	YES	NO_CAB_CALL_MAX	*****	
155	*9	YES	NO_RET_STOP	*****	
156	*9	YES	NO_TIEMPO_ET	*****	
157	NO	NO	PULS_STUCK	Push-button stuck (See "fault sub-codes" for more information)	
158	*9	YES	NO_RET_RBB	*****	
159	*9	YES	NO_PREFER_SUP	*****	
160	*9	YES	NO_PREFER_INF	*****	
161	*9	YES	NO_LOBBY_1	*****	
162	*9	YES	NO_LOBBY_2	*****	
163	*9	YES	NO_PLANTA_BOMBEROS	*****	
164	*1	YES	NO_ENTRA_DRDCONT	Contactor K80.2 (star connection) or K80.1 (delta connection) not closing	
165	*1	YES	NO_CAE_DRDCONT	Contactor K80.2 (star connection) or K80.1 (delta connection) not opening	
166	*1	YES	FALLO_CPI	Vacon frequency converter not ready	
167	*8	YES	FALLO-PULSOS	Position sensor pulse fault	
168	*8	YES	CODE_FOT_F1	Position sensor pulse fault (additional information)	
169	*8	YES	CODE_FOT_F2	Position sensor pulse fault (additional information)	
170	*8	YES	CODE_FOT_F3	Position sensor pulse fault (additional information)	
171	*8	YES	START_SIN_DIRECCION	*****	
172	*F	NO	FALLO_EQUIPO_MP1_TKE	A required MP1 TKE module is not working	
173	*3	YES	SITUAC_RESCATE	Automatic rescue function activated.	
174	*3	YES	RESCATE_OK	Automatic rescue terminated correctly.	
175	*3	YES	RESCATE_ERROR	Automatic rescue terminated with error	YES
176	*9	YES	NO_COTAINTERMEDIA	*****	
177	*9	YES	NO_COTAINTERINF	*****	
178	*9	YES	NO_COTAINTERSUP	*****	

179	*1	YES	FALLOCANHUECO	Fault in lift shaft CAN bus	
180	*1	YES	FALLOCANGRUPO	Fault in lift group CAN bus	
181	*9	YES	PARAM_ENCODER	Error in a parameter related to the encoder position	
182	*9	YES	MEDIDA_ENCODER	Invalid lift-shaft readings	YES
183	*9	YES	PULSOS_ENCODER	Fault in encoder pulse signal	
184	*9	YES	SINCRO_ENCODER	The positioning does not coincide with the lift-shaft dimensions	
185	*9	YES	LOGICA_ENCODER	General encoder fault	
186	*9	YES	FALLO_CM_SECUNDARIO	Supplementary mechanical change-over does not correspond to "CMB" and "CMS" speed changes	
187	*F	NO	FALLO_DMC	DMC device not connected or not correctly initialized.	
188	*F	NO	FALLO_OP	UCO device or CAN door control not connected or not correctly initialised. (See "fault sub-codes" for more information)	YES
189	*F	YES	FALLO_BTN_LIN	Fault in a board (BMC/IMC) in the car button panel	
190	*1	YES	FALLO_PARADA_ELECTRICA	When stopping, the frequency converter does not complete electrical stopping. Electrical stop state not received from the frequency converter CAN	
191	*1	YES	SCNA_NO_ABRE_PARADA	*****	
192	*1	YES	FALLO_ESP_PARADA	When stopping, the frequency converter does not permit the motor contactor to open	
193	*1	YES	SCNC_NO_CIERRA_PARADA	*****	
194	*1	YES	FALLO_SCNCNAO_VARIADOR-	*****	
195	*1	YES	SCNC_NO_ABRE_ARRANQUE	*****	
196	*1	YES	FALLO_SECUENCIA_ESP_ARRANQUE	When the Vacon frequency converter starts, it does not activate the motor field winding.	
197	*1	YES	FALLO_SECUENCIA_EBS_ARRANQUE	When starting, the frequency converter does not allow the brake to open	
198	*1	YES	SCNA_NO_CIERRA_ARRANQUE	*****	
199	*1	YES	FALLO_CAE_RUN_VARIADOR_CAN	The frequency converter run signal is lost while the lift is moving	
200	*3	YES	SITUACION_TEST_DE_FRENO	The control unit is in the brake test mode	
201	*1	YES	ERROR_TEST_DE_FRENO	The brake test has terminated incorrectly (see "fault sub-codes" for more information)	YES
202	*1	YES	FALLO_INTENSIDAD_VARIADOR_CAN	Unexpected current detected in the frequency converter transformer	
203	*1	YES	AVERIA_VARIADOR	The frequency converter has signalled a fault (see "fault sub-codes" for more information)	YES
204	*1	YES	VARIADOR_EN_FALLO	Frequency converter fault detected	
205	*1	YES	APERTURA_SERIE_PARADA	Safety switch chain opened while stopping	
206	*1	YES	APERTURA_SERIE_ARRANQUE	Safety switch chain opened while starting	
207	*E	YES	FALLO_REGENERATIVO	Regenerator equipment fault	
208	*B	NO	AVISO_SAI	UPS battery discharged	YES
209	*B	NO	AVERIA_SAI	UPS indicates battery test failure	
210	*F	NO	ERROR_PASARELA_USB	USB Communications gateway fault	
211	*G	YES	ERROR_SIN_TARADO	Tare weight not set correctly for weighing loads in belt-driven lifts	
212	*G	YES	ERROR_MEDIDA_DM	Weighing system gives incorrect readings in some gauges (belt-driven lifts)	
213	*G	YES	ERROR_DESEQUILIBRIO_DMC	Uneven tension in a drive belt	
214	*G	YES	CORREAS_MAX_VIAJES	Maximum journeys with direction switching reached in belt-driven lifts	
215	*G	YES	CORREAS_MONTAJE	Belt-driven lift under construction	
216	*A	YES	TEST_ACUÑAMIENTO_CORREAS	Belt-driven lift in lock-up test	
217	*1	YES	NO_ENTRA_BRK3	Brake contacts supervision, contactor BRK3 not closing (belt-driven lifts with a third brake)	
218	*1	YES	NO_CAE_BRK3	Brake contacts supervision, contactor BRK3 not opening (belt-driven lifts with a third brake)	
219	*1	YES	FALLO_SCNA_NO_ABIERTA	*****	
220	*1	YES	FALLO_SCNC_NO_CERRADA	*****	
221	NO	NO	FALLO_DISP_I2C	Fault in communications with an I2C device	
222	NO	NO	PARO_SIN_VEL_0	Stop landing magnet reached with no speed signal from the Vacon frequency converter	
223	NO	NO	ANTINUISANCE_ON	Calls from the car dismissed due to the anti- nuisance function.	
224	*0	YES	FALLO_TEMP_OPERADOR	Over-heating fault in the door mechanism	
225	*0	NO	FALLO_CIERRE_PUERTA_CABIN	The door activated control signal is not activated in a door bypass situation	
226					
227					
228					
229					

230					
231					
232					
233					
234					
235					
236					
237					
238	NO	NO	---	Access error via LCA1 interface	
239					
240					
241					
242					
243					
244					
245					
246					
247					
248					
249	NO	NO	REINICIO_DE_MANIOBRA	The control unit has reinitialised.	
250	NO	NO	FALLO_PARAMETROS	Reset default parameters	
251	NO	NO	RST_PILA_AVERIAS	Fault stack reset or erased. Indicates when the fault stack was last erased	
252	NO	NO	INICIALIZANDO	Control unit initialised	
253	NO	YES	RESET	Manual reset performed	
254	NO	YES	FALLO254	Generic fault	
255	--	--	No usado	--	



thyssenkrupp

Prepared by: R.Alonso
Checked by: A
Date: 21/11/2016

Department: R&D

2785.79_H02

LIST OF FAULTS CMC4+20.50

CODE	NEMONIC	LOCALIZER	FAULT SUB-CODE CMC4+20.50
43	FALLO_PROTEC_SALIDAS	0	General fault in short-circuit detection circuit
		1	_EnFRENOTEST
		2	_OMI2
		3	_OMI1
		4	_T3_UCM
		5	_LS
		6	_V_PAS
		7	_No_Usada1
		8	_No_Usada2
		9	_OUT_AUX_6
		10	_OUT_AUX_5
		11	_OUT_AUX_7
		12	_No_Usada3
		13	_SANS
		14	_AVERIA
		15	_TEACH_T
		16	_TEACH_F
		17	_V2
		18	_releK3_ls
		19	_releK2_dw
		20	_releK4_hs
		21	_releK1_up
		22	_releK5_rev
		23	_releK8HF49
		24	_releK6_rbr
		25	_OUT_PROG
		26	_VINS
		27	_K01_CONTA
		28	_No_Usada4
		29	_OUT_AUX_3
		30	_OUT_AUX_4
		31	_OUT_AUX_1
		32	_OUT_AUX_2
85	NO_UCPS_TRASERO	N	Indicates the floor on which the fault was detected
86	NO_UCPS_FRONTAL	N	Indicates the floor on which the fault was detected
87	MAS_UCPS_FRONTAL	N	Indicates the floor on which the fault was detected
88	MAS_UCPS_TRASERO	N	Indicates the floor on which the fault was detected
147	FALLO_PARAM_EEPROM	1	top_level
		2	low_level
		3	num_basament
		4	motor_code
		5	control_code
		6	doors_type
		7	front_opertor_type
		8	double_access
		9	.

		10	rear_operator_type
		11	hd_starter
		12	pre_opening
		13	re_levelling
		14	relevel_tries
		15	relevel_uptime
		16	relevel_downtime
		17	relevel_timeout
		18	.
		19	outofservice_mode
		20	outofservice_priority
		21	rushhour_trends
		22	upward_trend_level
		23	downward_trend_level
		24	noclose_trends
		25	selfpark_mode
		26	selfpark_level
		27	selfpark_time
		28	grp_evacuation_control
		29	grp_evacuation_level
		30	grp_evacuation_time
		31	grp_evacuation_oof
		32	nudging_mode
		33	reopen_delay_en
		34	reopen_delay_time
		35	landcall_reopen
		36	firefighter_en81_72
		37	firemen_portugal
		38	firefighter_level
		39	opening_buzzer
		40	ever_stop_function
		41	ever_stop_level
		42	door70T_inter
		43	door70T_lobby
		44	doors_max_time
		45	closing_tries
		46	opening_tries
		47	conex_per_hour
		48	conex_reserve
		49	highspeed_timeout
		50	lowspeed_timeout
		51	max_n_carcalls
		52	hd_delay_stop
		53	delay_before_start
		54	delay_after_stop
		55	hd_stardelta_time
		56	electrocam_type
		57	electrocam_time
		58	prefer_top
		59	prefer_low
		60	lobby1_level
		61	lobby2_level
		62	ls_contactor_delay
		63	up_contactor_delay
		64	display_ls_time
		65	inhibited_level
		66	inhibited_frontdoor
		67	inhibited_reardoor
		68	inhibited_closing

	69	display_ls_code
	70	shaftflag_type
	71	park_type
	72	park_time
	73	park1_level
	74	park2_level
	75	park3_level
	76	park4_level
	77	lantern_mode
	78	frontucps_location
	79	rearucp_location
	80	ucc_location
	81	ucc_location
	82	controller_location
	83	grp_elevator_number
	84	obs_vvuf_cpi
	85	display_ascii_text
	86	land_display_type
	87	car_display_type
	88	cabinet_display_type
	89	carlight_timeoff
	90	landingcall_buzzer
	91	carcall_buzzer
	92	nudging_time
	93	shortfloor_zone
	94	selective_access
	95	front_landdoor_type
	96	rear_landdoor_type
	97	distance_floor
	98	grp_land_register_mode
	99	pit_overhead_reduced
	100	check_brake_switch
	101	shabbat_elevator
	102	shabbat_time
	103	shabbat_time2
	104	inter_upper_level
	105	inter_lower_level
	106	inspection_wait_out
	107	vane_timeout
	108	antinuissance_calls
	109	dblclk_cancelcall
	110	input1_prog_function
	111	input1_prog_contact
	112	use_encoder
	113	reduction_numerator
	114	reduction_denominator
	115	car_suspension
	116	ppr_encoder
	117	pulley_diameter
	118	distance_vn
	119	distance_v2
	120	evacuation_en81_73
	121	upstop_delay
	122	dwstop_dalay
	123	door_unlock_timeout
	124	callregister_type
	125	carcall_vip_time
	126	carfree_vip_time
	127	grp_vip_mode

		128	aux_lowtop_switches
		129	waychng_removecall
		130	auto_summer_time
		131	display_voice
		132	display_image
		133	toplevel_correction
		134	energy_saving_time
		135	running_doorclose_time
		136	door_operator_traction
		137	carkey_fireservice
		138	attika_function
		139	attika_user_time
		140	attika_visitor_time
		141	attika_rescue
		142	grp_function
		143	control_ucmA3
		144	rescue_between_cars
		145	inspection_max_time
		146	flooded_level
		147	encoded_carcall
		148	ext_fireservice_control
		149	input2_prog_function
		150	input2_prog_contact
		151	mp1_prog_function
		152	mp1_prog_contact
		153	grp_exclusivland_mode
		154	config_dmc
		155	load_car_max
		156	belt_drive_wgt
		157	control_rope_wgt
		158	compesation_chain_wgt
		159	distance_v2B
		160	distance_v2c
		161	distance_v2d
		162	rescue_mode
		163	rescue_level
		164	fan_mode
		165	fan_time
		166	motor_model1
		167	motro_model2
		168	regenerative_system
		169	grp_penalty_iddle
		170	belts_traction
		171	ups_comunication
		172	bms_system
		173	next_landing
175	RESCATE_ERROR	13	Fault in CAN communications with the frequency converter
		14	Regeneration fault
		15	Maximum rescue time exceeded
		16	Lift will not start
		17	Ratchet coil A3
		18	Fault in communications with the car
		19	Rescue output due to an inspection or an emergency
		20	Cannot close doors
		21	Cannot open doors
		22	Interlock or presence chain open
		23	Safety chain open
		24	Excess speed (RE not operating)

		25	Car balanced
		26	Floor not reached in maximum rescue time
		27	Floor not reached in maximum rescue time and no encoder pulses detected
		28	Brake microswitches not opening
		29	NC contactor chain not opening
		30	When commencing rescue the brake microswitches are not in idle position
		31	When commencing rescue the NC chain is not in idle position
182	MEDIDA_ENCODER	0	Floor less than 100 mm
		1	Two consecutive floors less than 1,900 mm
		2	The measured CMB distance does not coincide with parameter distance_VN (tolerance 500 mm)
		3	The measured CMS distance does not coincide with parameter distance_VN (tolerance 500 mm)
		4	Free
		5	Free
		6	Magnet count does not coincide with the upper and lower limit parameters
		7	Pulse counter overflow.
188	FALLO_OP	32	Front not ready
		33	Front not responding
		34	Front over-temperature
		35	Incompatible front firmware version.
		64	Rear not ready
		65	Rear not responding
		66	Rear over-temperature
		67	Incompatible rear firmware version.
201	ERROR_TEST_DE_FRENO	1	At start of test, the brake microswitches are not activated
		2	No brake microswitch engaged in static test
		3	Brake A not released in static test
		4	Brake B not released in static test
		5	Movement detected in static test A
		6	Movement detected in static test B
		7	Attempt to test same brake-block
		8	Security, interlock or presence circuits open
		9	Brake test incomplete
		10	Time to detect landing magnet
		11	Measurement error in dynamic brake test
		12	Return time from dynamic rescue exceeded
		13	Fault starting dynamic brake test
		14	Fault in brake test sequence
203	AVERIA_VARIADOR	*	See "Fault codes" in the "Vacon-Thyssenkrupp Quick-Start Guide"
208	AVISO_SAI_	0	
		1	Fault in i2c device
		2	UPS not responding
		3	Test error

Version	Modifications	Date	Written by/Checked by
A	First version	21/11/2016	R.Alonso/C.Villena