

HEX@ Controller

USER INTERFACE INSTRUCTION MANUAL

P50100000_A Original instructions

Copyright notice

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers and drawings. This instruction book is valid for CE as well as non-CE labelled machines. It meets the requirements for instructions specified by the applicable European directives as identified in the Declaration of Conformity.

Trademark credit

©2021 Atlas Copco AB, Stockholm, Sweden.

Disclaimer

The content of this manual may change from time to time without notice. We accept no liability for any errors that may appear in this manual nor do we make any expressed or implied warranties regarding the content. As far as practical we have ensured that the products have been designed and constructed to be safe and without risks when properly installed and used in accordance with their operating instructions.

We accept no liability for loss of profit, loss of market or any other indirect or consequential loss whatsoever.

Product warranty and limit of liability are dealt with in our standard terms and conditions of sale or negotiated contract under which this document is supplied.

You must use this product as described in this manual. Read the manual before you install, operate, or maintain the product.

Contents

1.	Introducing the controller	. 5
	1.1. Accessing User Interface	. 5
	1.1.1. Troubleshooting Windows connection problems	. 5
	1.1.2. Entering login credentials	. 6
	1.1.3. Viewing controller home page	. 6
	1.2. Using Discovery application for finding the pump	. 7
	1.3. List of abbreviations	8
2.	Configuring the controller	9
	2.1. Connecting the pump to the local LAN network	
	2.2. Setting the preferred language	9
	2.3. Setting the physical units	9
	2.4. Setting the date and time	10
	2.5. Creating user profile for customer	10
	2.6. Setting the HMS WiFi bolt	10
	2.6.1. Connecting WiFi to the company network	10
	2.6.2. Creating a separate local network with WiFi bolts	11
	2.6.3. Connecting to a local network with WiFi bolts	
	2.7. Changing display settings	12
	2.8. Backup and restore parameter setting	12
	2.9. Updating the software	
	2.9.1. Troubleshooting software update failure	13
	2.10. Allowing remote assistance (optional)	
	2.11. Checking the pump efficiency (KPI functions)	
	2.12. Checking the trend mechanism	
	2.12.1. Using trend actions	
	2.12.2. Viewing chart settings	
	2.12.3. Modifying pump sensors on Home page	
	2.13. Checking the service interval (Pump maintenance)	
	2.14. Setting a custom digital output function	
	2.15. Enabling remote speed control	
	2.16. Enabling remote pressure setpoint control	
	2.17. Finding the pump information	19
	2.18. Getting help	19
3.	Operating the pump	20
	3.1. Verifying main operating conditions	20
	3.2. Changing the connection mode	20
	3.2.1. Viewing front panel controls	21
	3.3. Starting and stopping the machine	21
	3.4. Changing the pressure setpoint	
	3.5. Setting the pump modes.	22

3.6.	Adjusting the pump settings	23
3.7.	Changing the pump mode	23
3.8.	Forcing the machine to run at maximum speed	24
3.9.	Starting the pump automatically after a supply voltage interruption	24
3.10). Setting the schedules	25
3.11	Responding to an alert	25

11/2021 - ©Atlas Copco

1. Introducing the controller

The controller starts and stops the pump, adjust the pressure setpoints, and monitors alerts. You can also collect data and analyse pump performance to improve processes and lower your operating costs.

1.1. Accessing User Interface

You can access the controller from any device connected to the same network (Windows PC, smartphone, tablet, laptop,...)

A Discovery app is available to locate the controller connected to the local network with the help of the IP address.

To access the controller

- 1. Click the browser's address bar.
- 2. Type the IP address, 192.168.202.10 and press Enter.
- To change the display language
 - 1. Click on the Flag icon.
 - Select the language of your choice.The notifications are displayed along with the Bell icon.
- 4. To Sign-in
 - 1. Click on Sign in button
 - 2. Type Username and Password.
 - Click Sign in.
 - 4. Use your login credentials or the credentials available on the sticker found on the machine.








1.1.1. Troubleshooting Windows connection problems

If you cannot access the IP address, 192.168.202.10 in your web browser,

- 1. Press the "Windows" button on the keyboard.
- 2. Search "View network connections".
- 3. Right click on **Ethernet** or **Adapter** (depending on the ethernet connection).
- Click Properties > Internet protocol version 4 (TCP/IPv4) > Properties >
 Use following IP address.
- 5. Enter IP address as 192.168.202.9.
- 6. Click on **Subnet mask** and 255.255.255.0 number must appear.
- 7. Click OK.

Try to connect through your web browser again.





1.1.2. Entering login credentials

To use first time sign-in

1. Click First sign-in tab First sign in page displays



- 2. Type Username
- 3. Type Password
- 4. Click OK

You can change login credentials after your first login.


Entering new password

If you forgot your Username and Password

- 1. Go to the Forgot Password tab.
- 2. Enter the details from the controller hardware label.

1.1.3. Viewing controller home page

The default home page displays after the first login.



The home page is divided into four segments

Section	Functions
Navigation bar	You can see key parts of controller such as Home Controls Trends Settings Schedule Maintenance Alarms More
KPI functionalities	You can see pump parameters such as Uptime, Performance, Eco and Health.
Pump sensor values	You can see pump sensor values.
KPI insight card	You can see KPI functionalities.

1.2. Using Discovery application for finding the pump

To find the pump through the Discovery application

- 1. Navigate to the App store or Google play store of your mobile device.
- 2. Search the IP discovery application.
- 3. Download the IP discovery application.

■ Note:

Make sure that the network connection is same for the controller and search engine. To do so, check the connection from controller to the customer end connection.

4. Open the application window.



5. Click on the pump card to display the network IP address.

1.3. List of abbreviations

Table 1 Abbreviations

HEX@	HEX@AtlasCopco controller
UI	User Interface
НМІ	Human Machine Interface
IP address	Internet Protocol address
DNS	Domain Name System
DHCP	Dynamic Host Configuration Protocol
mDNS	Multicast DNS
M2M	Machine to Machine
MQTT	Message Queuing Telemetry Transport

2. Configuring the controller

Configure the controller for your situation and usage.

2.1. Connecting the pump to the local LAN network

■ Note:

Connect the controllers directly to the company network through the X11 port on the rear of the controller with Ethernet cables.

To connect to the controller

- Navigate to the IP address in a web browser.
 If you do not have the IP address, use X10 access (OP0020).
- 2. Click Sign in.
- Enter login credentials to access the home page.
- 4. Click More > Preferences > Connectivity > LAN.
- 5. Check and confirm with the IT department, if the DHCP has been set automatically.
- If the DHCP is set automatically, the connection is complete.
- If the DHCP is not set automatically, connect the ethernet manually

■ Note:

If the DHCP is enabled, the connection details will be selected automatically. If it is not displayed, enter the details manually.

- A. Click Edit.
- B. Deactivate **DHCP**.
- C. Enter the connection details manually.
- D. Click Save.
- E. Activate **Proxy** if you have to add the Proxy IP address.

2.2. Setting the preferred language

To set your desired language

- 1. Click More.
- 2. Navigate to **Preferences > General > Language.**
- 3. Select the preferred language.

2.3. Setting the physical units

To set the physical parameters units

- 1. Click More.
- 2. Navigate to **Preferences > General > Units**.
- 3. Modify the units for different parameters as per your requirement

2.4. Setting the date and time

To set the date and time

- Click More.
- 2. Navigate to **Preferences > General > Date and time**.
- 3. Modify the time zone, date and time, format of date and time as per requirement.

2.5. Creating user profile for customer

■ Note:

You must create an admin profile for the user (tier level 1). The admin can use his access to create different user profiles for their use.

To create the user profile

- 1. Click More > Manage users > Add user.
- 2. Enter the user details.
- Click Save user.

2.6. Setting the HMS WiFi bolt

2.6.1. Connecting WiFi to the company network

■ Note:

The controllers can be connected directly to the company network through the X11 port using the Client mode of the WiFi bolt.

To connect the controller to the WiFi connection

- 1. Navigate to the IP address in a web browser.
- 2. Click Sign in.
- 3. Enter your credentials to access the home screen.
- 4. Click More > Preferences > Accessories > WiFi bolt.
- Configure the WiFi bolt
 - Enable the WiFi bolt.
 - B. Make sure that the WiFi bolt is connected.
 - C. Press the **Refresh** button (visible only when the WiFi bolt is not connected).
 - D. Select Client mode.
 - E. Click **Scan** to see the access points.
 - F. Select the **WiFi access point** to connect.
 - G. Select the Authentication mode.
 - H. Enter Password.
 - I. Click Connect.



6. Repeat the process for all the devices that you want to connect to the customer network through WiFi.

2.6.2. Creating a separate local network with WiFi bolts

■ Note:

If you do not want a direct connection between the controller and your network, create a separate local network by an access point.

The controllers can connect directly to the customer network through the X11 port using the Client mode of the WiFi bolt.

To create a separate local network with WiFi bolts

- 1. Connect the WiFi bolt to the pump.
- 2. Navigate to IP address in a web browser.
- 3. Click Sign in.
- 4. Type your credentials to access the home page.
- 5. Click More > Preferences > Accessories > WiFi bolt.
- 6. Configure the WiFi bolt
 - Enable the WiFi bolt.
 - B. Check that the WiFi bolt is connected.
 - C. Press the **Refresh** button (visible only when the WiFi bolt is not connected).
 - D. Change connection mode to **Access Point**.
 - E. Create the access point by typing the name (SSID).
 - F. Set **Password** if required.
 - G. Set the **Authentication mode** to WPA2.

2.6.3. Connecting to a local network with WiFi bolts

To connect to a separate local network with WiFi bolts

- 1. Navigate to the IP address in a web browser.
- Click Sign in.
- 3. Use your credentials to access the home screen.
- 4. Click More > Preferences > Accessories > WiFi bolt.
- 5. Configure the WiFi bolt
 - Enable the WiFi bolt.
 - B. Make sure that the WiFi bolt is connected. If not, press the Refresh button (visible only when the WiFi bolt is not connected).
 - C. Change connection mode to Client.
 - D. Click **Scan** to see the access points.
 - E. Select the **WiFi access point** to connect.
 - F. Select the **Authentication mode**.
 - G. Enter Password.
 - H. Click Connect.



6. Repeat the process for all the devices that you want to connect to the customer network through WiFi.

2.7. Changing display settings

To change the display settings

- 1. Click More.
- 2. Navigate to Preferences > Accessories > HMI menu.
- 3. Modify the brightness, zoom and colour palette of the HMI as per your requirement.

2.8. Backup and restore parameter setting

This feature enables the user to backup and restore the parameters saved in the settings.

To backup the parameter values:

- Navigate to Settings.
- 2. Click top right icon.
- 3. Click Backup locally.

To restore the parameter settings:

- 1. Navigate to **Settings**.
- 2. Click top right icon.
- 3. Click restore parameters from file.
- 4. Upload the backup file from your location and upload.

2.9. Updating the software

To update the software offline and online

Updating the software offline

Update the software offline by manually updating .tar file from the controller.

- 1. Click More.
- Navigate to Preferences > Software update.
- 3. Click **Manual upload** on the top right corner.
- 4. Go to Instruction window, drag-drop the .tar file in the instruction window. (Make sure that the file name is correct.)
- 5. Click Upload file > Install update > Done.

Updating the software online

Update the software online by updating automatically from the controller.

Note:

Make sure to stop the pump before you do the software update.

1. Click **Download update file** which has been received from the cloud.



2. Click Install update > Done.

2.9.1. Troubleshooting software update failure

There is a chance of failure when updating the software. To fix the failure issue

- 1. Click View log.
- 2. Click Failed updates.
- Check more information on failed updates.
- 4. Click Download log.
- Restart the controller.
- 6. Repeat the software update.
- 7. If the problem persists
 - Click on Download log.
 - Send the log file and the software update file (if available) through TechConnect to the second level support.

2.10. Allowing remote assistance (optional)

■ Note:

You can access the controller through TeamViewer. This feature is available on request. Contact us for details.

To access the TeamViewer support for remote assistance

- 1. Click More.
- 2. Navigate to Support.
- 3. Click TeamViewer.

2.11. Checking the pump efficiency (KPI functions)

The controller monitors four Key Performance Indicators, known as pump KPI's. These are Uptime, Performance, Health and Eco. You can access these on the home page of the controller. Click on them to see their historical values.

Uptime	This indicates if the system was available when vacuum was required. It considers the maintenance times and the pump availability.
Performance	This indicates if the system is performing well. Performance is dependent on the application and the below points: • if the pressure stability is around the target pressure • if the pump down time is consistent
	if the response time of the machine is quick

Eco	This indicates the environmental impact of the machine. It evaluates if the machine could save more energy, for example running at lower speeds below the target pressure. Depending on the pump technology it will monitor the consumption of water or gases. This KPI will evaluate the benefit of an energy recovery option.
Health	This indicates the system health. It evaluates how long the machine has been running without failure or a warning. It will evaluate if the machine needs service as defined by the promised service due and if any parts of the machine act in an expected matter.

KPI Insights

The KPI insights are insight cards that give more information about the KPI's.

The Insight cards are presented on the home page and can be considered as tips to improve the pump KPI's.

2.12. Checking the trend mechanism

To check the trend mechanism

- 1. Navigate to **Trends**.
- 2. Navigate to the required function (Airflow, Power, Pressure, Temperature, Water flow) tab.

To add the variables as favourites

- 1. Click on the top right corner of the card.
- 2. Select Add to favourites.


■ Note:

Click on a variable to view the Variable Range.

The flexibility to add trends based on the preference and save the settings. Charts are grouped into types of measurements that can contain multiple charts.



Figure 1 Checking the trend mechanism



2.12.1. Using trend actions

To access the options in variable tab click the dots at the top right corner.

- add/remove from favourites
- details of function of respective variables


2.12.2. Viewing chart settings

The chart settings allow you to choose the trigger values for different parameters.

To access the Chart settings

- 1. Click Scope > Settings.
- 2. Choose from Rising or Falling for Trigger on.
- 3. Select the time before and after triggers as per your requirements.

Figure 2 Chart settings



2.12.3. Modifying pump sensors on Home page

To select the featured items position from Trends page on home page

1. Navigate to **Trends** page.

- 2. Click top right anchor on the tiles
- 3. Select Add to featured.
- 4. Select the Slot.
 - Slot1 Top left
 - Slot2 Top right
 - Slot3 Bottom left
 - Slot4 Bottom right

Figure 3 Modification of pump sensors on the home screen




Figure 4 Slots



2.13. Checking the service interval (Pump maintenance)

Navigate to the Maintenance screen to check the upcoming service intervals. Different service intervals are displayed based on the machine type and severity of the operating conditions. Each interval indicates the time left before the service must performed. This can be an amount of running hours or after a fixed period. Click on a specific service interval to see additional service information.

11/2021 - ©Atlas Copco

2.14. Setting a custom digital output function

The machine has three digital outputs that gives additional feedback signals to external hardware.

The three outputs by default, are set up as follows:

- Dout_E1 is enabled if the machine is started
- Dout E2 is disabled if the system has a warning
- Dout E3 is disabled if the system has a failure

The outputs can give other feedback signals as well.

To set a custom digital output

- 1. Navigate to Settings > Multi functional digital outputs.
- 2. Change the Active function code.

When set to a value different than 0, a specific function is activated to control this digital output. Refer to *Table: Function codes* for a list of function code.

Table 2 Function codes

Function code	Function
2	Indicates that the machine is started
3	Indicates that the machine has a warning
4	Indicates a failure
5	Indicates that a connection to the cloud is done
6	Indicates that the system is ok without warning or failure
7	To start a fixed speed booster when the process pressure is below a threshold and the backing pump is running. Only available if the fixed speed booster option is installed.
8	Indicates that the machine is producing vacuum (open inlet valve)
9	Indicates that the machine is running a pre purge cycle (heating up)
10	Indicates that the machine is running a post purge cycle (machine keeps itself heated ready for operation)
11	Indicates that the Pumpdown optimization function is activated (Only available if the Pumpdown optimization option is installed)
12	Indicates that the pressure is above the pressure setpoint
13	Indicates that the machine is performing a leak detection cycle (only available when the leak detection option is installed)
14	Indicates that the machines is running a purge cycle (pre, post or manual purge)

Function code	Function
15	Can be used as a custom pressure switch function, meaning the output will be enabled below or above a settable pressure level
16	Indicates that the motor is running above minimum speed
18	Indicates that the emergency stop is in a safe position (not tripped)
19	Indicates that the fan circuit breaker is enabled (not tripped)
20	Indicates that the remote start digital input is enabled
21	Indicates that the manual purge digital input is enabled
22	Indicates that the remote digital setpoint selector is ena- bled
23	Indicates that the remote maximum speed input is enabled

2.15. Enabling remote speed control

The machine is by default equipped with a remote or analog speed control functionality. It is possible to control the machine speed from an analog input, overwriting the machines own pressure setpoint control. The machine will limit the requested speeds in case they are outside of its allowed range.

To enable the remote speed control

- 1. Connect a 0 20 mA or 4 20 mA 2-wire connection to the AIN_E4 connector pins 11 and 12 on connector X1.
- 2. Navigate to **Settings** menu.
- 3. Search for the Multi Functional analog inputs.
- Set the Al_E4_0_20mA.ActiveFunctionCode to 1 to enable the remote speed control. The controllers external input AIN_E4 is now used for this functionality.

2.16. Enabling remote pressure setpoint control

The machine is by default equipped with a remote or analog speed control functionality. It is possible to control the machine speed from an analog input, overwriting the machines own pressure setpoint control. The machine will limit the requested speeds in case they are outside of its allowed range.

To enable remote pressure setpoint control



- 1. Connect a 0 20 mA or 4 20 mA 2-wire connection to the AIN_E4 connector pins 11 and 12 on connector X1.
- 2. Navigate to **Settings** menu
- 3. Search for the Multi Functional analog inputs.
- Set the Al_E4_0_20mA.ActiveFunctionCode to 2 to enable the remote setpoint control. The controllers external input AIN_E4 is now used for this functionality.


2.17. Finding the pump information

To find the pump information, click **More > About this pump.**

2.18. Getting help

It displays the anchor points on top right corner of each page with topics related to that particular page. If you go to the particular topic you can find the information about the functionality.

Figure 5 User friendly manual



3. Operating the pump

Start the pump, view the status, pressure, motor speed, and outlet temperature. Change pressure setpoints, change the mode between load-dependent or fixed-speed modes, adjust automatic restart, or set schedule actions.

3.1. Verifying main operating conditions

By looking at menu bar you can check the main operating conditions of the pump . The menu bar includes following

- 1. Pump running status
 - Off The pump is ideal and waiting for a start command
 - VacuumControl The pump is in operation and generates vacuum at its inlet
 - Failure The pump has a critical error. It needs to be investigated and reset before the pump re-start.
 - PrePurge/PostPurge/ManualPurge The pump heat up to the desired operating temperature without generating vacuum.
- 2. Inlet pressure
- 3. Motor speed
- 4. Outlet temperature

You can see the pump operating condition by navigating to home page.

■ Note:

The load of the pump indicates how fast the pump is running. 100% means that the pump is at its maximum speed and cannot produce more flow.

3.2. Changing the connection mode

You can change the pump connection mode from the **Controls** screen. No other source than the one selected can start or stop the pump.

The most common connection modes are:

- Front panel It is used when the control panel installed on the pump without HMI.
- Fieldbus It is used when external PLC controls the pump over ethernet.
- Hardware IO the hard-wired connections (if installed).
- Central system It is used when the pump is part of a central vacuum system.
 In this case an overruling central controller will control all different pumps together.
- Local web UI -It is used when the HMI installed on the pump.
- Remote web UI It is used when the interface is accessed from external devices like laptop or phones.




3.2.1. Viewing front panel controls

There are following four icons on the front panel that influence the start and stop command.

- 1. Start/Stop icon It is a lit up LED which indicates that the pump is in operation.
- 2. Mode icon It switches the mode on the pump. A LED is lit up to indicate the active mode.
- 3. Connection mode icon It declares the source of pump control.
 - A lit up LED indicates that the pump can be controlled from the front panel.
 - A non-lit LED indicates that the pump is controlled from a different source like from an external PLC.
- 4. Reset icon It resets a failure on the pump after the problem is solved.

Figure 6 Change the connection mode



3.3. Starting and stopping the machine

You can start or stop the pump through the controller. Press the green or red button to start or stop the pump respectively.

- A dark green button indicates that the pump is off and can be started.
- A dark red button indicates that the pump is in operation and can be stopped.
- A greyed out button indicates that the pump cannot be controlled from this interface because the connection mode is not set to this controller.

Figure 7 Different colors of the start/stop button on the Controls page



3.4. Changing the pressure setpoint

To change the pressure setpoint, proceed as follows:

- 1. Navigate to **Settings.**
- 2. Navigate to Pressure setpoint control.
- 3. Modify the settings to tune the pumps control to the process requirements.
 - Setpoint1 Indicates pressure setpoint value number 1
 - Setpoint2 -Indicates pressure setpoint value number 2
 - SetpointSelection Indicates which pressure setpoint is active.
 - Offset & MinRunTime Indicates both settings are used to decide when the machine can go to standby.

If the process pressure is smaller than the pressure setpoint, the machine will slow down and eventually shut off to save energy. It shuts off automatically when

- The inlet pressure is below the setpoint minus the offset.
- The machine speed is very slow for a minimum time dictated by the MinRunTime.

3.5. Setting the pump modes

The pump modes allows the user to setup pump operations.

There are 4 modes available:

- Default mode: This mode is intended for use in central vacuum applications with some variability in load. The pump operating speed will adjust as a function of the inlet pressure vs the target Setpoint with a medium level of reactivity.
- Fixed speed mode: This mode is intended for cyclic applications with a holding period. The pump will run at 100% of it's maximum speed until the target pressure is reached, then it will switch to the inputted holding speed until the inlet pressure rise and reaches the target Setpoint. The pump will not stop running like in PI control and stay ready to ramp up to maximum speed at any moment.
- Slow PI: This mode is intended for use in central vacuum applications with some variability in load. The pump operating speed will adjust as a function of the inlet pressure vs the target Setpoint with a medium level of reactivity.



Force max speed: This mode is intended for use in cyclic applications. The pump will ignore the PI control method and run at 100% maximum speed. It can also be used during commissioning to check the ultimate pressure of the vacuum pump in the given installed conditions.

The user can activate any modes

- 1. Click More.
- 2. Navigate to Modes.
- 3. Create a new mode or select the mode from available **Modes**.

To add settings for the different modes

- 1. Click Settings > Details.
- 2. **Add** the desired settings and details.
- Click Done.

3.6. Adjusting the pump settings

To adjust the pump settings

- 1. Navigate to More.
- 2. Click Mode > Default mode.
- 3. Set the values to fine tune the pump performance. In the Default mode, you can change following settings:
 - Force max speed
 - Proportional gain
 - Integral gain.

■ Note:


Change the values of proportional gain and Integral gain only in steps of 0.5 so that you do not damage the pump.

3.7. Changing the pump mode

You can change the pump mode from the front panel or the user interface. You can set the pump to Active mode directly from the controls page.

On the front panel a blinking led indicates the active pump mode (1, 2, 3 or 4). When you click on this icon, the next mode will have a blinking LED for a second before it becomes active.

Figure 8 Changing the pump mode



3.8. Forcing the machine to run at maximum speed


The pump is by default set to control its motor speed intelligently. The pump will regulate itself to maintain the inlet pressure equal to the user pressure setpoint.

To change the speed control function

- Navigate to Settings > Speed control settings.
- 2. Search forceMaximumSpeed.
- 3. Enable the Setting.

The pump will always run at its maximum speed.

Figure 9 Forcing the pump to run at maximum speed



3.9. Starting the pump automatically after a supply voltage interruption

The controller has a built-in function to automatically restart the vacuum pump if the voltage is restored after a voltage failure. By default this function is disable.

To set the pump to automatically restart

1. Navigate to **Settings > Advanced control settings**.

There are 4 settings influencing this functionality:

- Active Enables that the machine automatically restarts after a voltage failure if voltage is restored.
- AravfPowerDownTime Sets the maximum time for the machine to be without voltage and restart again when the voltage is restored..
- RestartDelay Sets a restart delay to the machine if the machine can automatically restart. This is useful in case multiple machines are set to restart at the same time.
- AravfPowerDownTimeInfinite Sets the AravfPowerDownTime to infinite.
 This means that the machine will restart after a voltage failure regardless how long it took to restore the voltage.

3.10. Setting the schedules

To create a new schedule, proceed as follows:

- Navigate to Schedule.
- Click New schedule.
- 3. Enter schedule name.
- 4. Click Create schedule > New event.
- 5. Select actions (Start pump, Stop pump, Start purge, Stop purge, Change mode) based on preference.
- 6. Select the **Interval type**.
 - A. If the Interval type is Timed
 - Enter start day, time and repeat information.
 - B. If the Interval type is neos-runningTime-Running hours, fan-switchCount-Counters, mainMotorRunEnable.-switchCount-Counters
 - Enter running hours

3.11. Responding to an alert

An alert can be recognised by a failure or warning message on the bottom of the home page.

- A failure will stop the pump and requires a manual reset. It is displayed in red.
 When the pump is in failure mode, it cannot be started before the root cause of the failure is gone and the failure has been manually reset.
- A warning will not stop the pump and does not require a reset. It is displayed in orange on the user interface.

To investigate the alert, failure or warning

- 1. Navigate to **Alerts**. You can see a list of all current alerts.
- 2. Select the specific alert to get more information about the possible root cause and the solutions.

If the failure is solved, click on **Reset pump** to reset the alert. You can also see the previously solved alerts by clicking on the history button.



Figure 10 Responding to an alert

