



LIGHTING & DMX *reference*

◆ PATCH SUMMARY

BAR	POSITION	DISTRO	FIXTURES	MODE	ADDRESS
Spot	Sound booth	-	1× MARQ Gesture Beam 400 (Xbox follow spot)	15 ch	1 to 15
Gallery	Gallery wall	-	Venue Tetra Bar	6 ch	20 to 25
Gallery	Gallery wall	-	Chauvet Abyss 2 (#1)	3 ch	26 to 28
Gallery	Gallery wall	-	Chauvet SlimPAR 64	7 ch	29 to 35
Gallery	Gallery wall	-	Chauvet COREpar 40 USB	8 ch	36 to 43
Gallery	Gallery wall	-	Chauvet Abyss 2 (#2)	3 ch	44 to 46
Gallery	Gallery wall	-	Venue ThinTri 64 (#1)	8 ch	47 to 54
Gallery	Gallery wall	-	Venue ThinTri 64 (#2)	8 ch	55 to 62
Bar 1	Audience side	A	4× Electro Controls Cat. 3486 / Type 34 Fresnel, 750W	dimmer	100 to 107
Bar 2		A	6× Chauvet COREpar 40 USB	8 ch	201 to 248
Bar 3	Center	A	4× SlimPAR 64 + 4× ThinTri 64 (alt.)	7 / 8 ch	301 to 360
Bar 4	Upstage of center	B	Open / reserved	-	-
Door bar	Over other door	-	Mystery wash + strobe bar (12 RGBW lens + SMD)	1 mode	400 + (count TBD)
Bar 5	Upstage	B	6× Altman 65Q 6" Fresnel, 750W	dimmer	500 to 507
Effects	Locker	-	1× Chauvet DJ Kinta FX ILS (derby + laser + strobe)	2 or 9 ch	TBD

Distro A feeds bars 1 to 3, Distro B feeds bars 4 to 5. Gallery wall cluster (20 to 62) and the booth spot (1 to 15) run on their own lines. Mystery bar at base 400: set its final end address once the channel count is read off the board.

◆ BAR 3 PER-FIXTURE ADDRESSES

POS	FIXTURE	MODE	START	END	POS	FIXTURE	MODE	START	END
SR1	SlimPAR 64	7 ch	301	307	SL5	SlimPAR 64	7 ch	331	337
SR2	ThinTri 64	8 ch	308	315	SL6	ThinTri 64	8 ch	338	345
SR3	SlimPAR 64	7 ch	316	322	SL7	SlimPAR 64	7 ch	346	352
SR4	ThinTri 64	8 ch	323	330	SL8	ThinTri 64	8 ch	353	360

Alternating from stage right, starting with the Chauvets. Bar 2 COREpars step by 8: 201, 209, 217, 225, 233, 241.

◆ CONVENTIONAL DIMMER BANKS

One DMX channel = one dimmer = one fixture intensity. Tungsten loads only. Bar 1: Electro Controls Cat. 3486 / Type 34 Fresnel, 750W each. Bar 5: Altman 65Q 6" Fresnel, 750W each. Both ~6.3A @ 120V per fixture.

BAR	PACK	CHANNELS	FIXTURES	LOAD (A @ 120V)
Bar 1	Pack 1	100 to 103	2 used, 2 spare	~12.6 A · 1.5 kW
Bar 1	Pack 2	104 to 107	2 used, 2 spare	~12.6 A · 1.5 kW
Bar 5	Pack 1	500 to 503	4	~25 A · 3.0 kW

BAR	PACK	CHANNELS	FIXTURES	LOAD (A @ 120V)
Bar 5	Pack 2	504 to 507	2 used, 2 spare	~12.6 A · 1.5 kW

Set each pack to DMX mode (not standalone / chase) and address sequentially. Bar 1 leaves 4 spare channels (102, 103, 106, 107) and Bar 5 leaves 2 (506, 507) for practicals or downlight specials. **Bar 5 Pack 1 draws ~25 A at full** (four 750W Fresnels): put it on a 30 A circuit and confirm the pack is rated for it. Bar 1 packs are an easy ~12.6 A each. Connected tungsten total at full: Bar 1 ~3.0 kW + Bar 5 ~4.5 kW = ~7.5 kW (~62 A). Watch heat.

◆ QLAB GROUPS (SO FAR)

GROUP	MEMBERS	COUNT	ADDRESSES
COREpar 40s	All Core PAR 40s (Bar 2)	6	201, 209, 217, 225, 233, 241
SlimPARs (Bar 3)	SlimPAR 64s on Bar 3	4	301, 316, 331, 346
ThinTris (Bar 3)	ThinTri 64s on Bar 3	4	308, 323, 338, 353
Bar 1 dimmers	Front dimmer fixtures	4	100, 101, 104, 105
Bar 5 dimmers	Upstage dimmer fixtures	6	500, 501, 502, 503, 504, 505

◆ QLAB QUICK-START – NON-TD LIGHTING GUIDE

Not a lighting person? No problem. Follow these steps in order and you will have the right lights for any situation.

STEP	WHAT TO DO	NOTES
1	Log into the tech computer	Ask the TD for the password if you don't have it.
2	Open QLab	Double-click the QLab icon on the desktop. It opens to the last show automatically.
3	Select the "Default" show	In the workspace switcher at the top, confirm it says <i>Default</i> . If not, go to File → Open and choose it.
4	Click the Lights tab	Along the top of the cue list you will see tabs. Click <i>Lights</i> to see only lighting cues.
5	Click the cue you need, then press Go (spacebar)	Find the right cue in the list below and hit the big green Go button or press the spacebar.

THE CUES

Rehearsal	Full work-light level. Use this during rehearsal, notes sessions, or any time people need to see clearly. Safe, bright, neutral.
Safety Lights	Low-level wash so people can navigate the space without tripping. Use during breaks, intermission, or any time the house is open but you are not in rehearsal.
Black Out	Everything off. Use at the top of a scene or when the director calls for a full blackout. Do not walk on stage in a blackout without calling "going to black" first.
Music	Activates sound-active multi-color mode on the LED pars. The fixtures react to the music automatically. Use for pre-show, intermission music, or a party vibe. Hit Black Out to stop it.

IF SOMETHING LOOKS WRONG

Lights didn't change	Make sure QLab is in the <i>Lights</i> tab and the DMX interface light on the back of the computer is solid (not blinking). Try the cue again.
One fixture is off	Check its DMX cable is seated. If it still won't respond, note which bar it is on and tell the TD.
Everything is wrong	Hit <i>Black Out</i> first to reset, then try the cue you need. If it is still wrong, call Dan: 814.490.0605 .
Need help fast	Call Dan: 814.490.0605 . Do not start pulling cables.

◆ FIXTURE CHANNEL MAPS

CHAUVET SLIMPAR 64

7 CHANNEL · RGB

1	Red (0 to 100%)
2	Green (0 to 100%)
3	Blue (0 to 100%)
4	Color macros (0 to 15 off, 16+ macros)
5	Strobe / speed / sound sens. (set by ch 6)
6	Programs / mode
7	Master dimmer

CHAUVET COREPAR 40 USB

8 CHANNEL · RGB COB

1	Red (0 to 100%)
2	Green (0 to 100%)
3	Blue (0 to 100%)
4	Color macros (0 to 15 off, 16+ macros)
5	Strobe / speed / sound sens. (set by ch 6)
6	Programs
7	Master dimmer
8	Dimmer speed

CHAUVET ABYSS 2

3 CHANNEL · WATER EFFECT (GALLERY RAIL)

1	Dimmer (0 to 100%)
2	Color wheel (pick or rotate)
3	Wave effect (direction + speed)

Ch 2 colors: 0 to 21 white, 22 to 42 magenta, 43 to 63 yellow, 64 to 84 cyan, 85 to 105 green, 106 to 127 orange, then 128 to 188 CCW spin, 189 to 194 stop, 195 to 255 CW spin. Ch 3 wave: 0 off, 1 to 122 CCW slow to fast, 123 to 133 stop, 134 to 255 CW. This model picks a specific color over DMX (the older 2 ch 3.0 cannot).

VENUE THINTRI 64

8 CHANNEL · RGB

1	Red (0 to 100%)
2	Green (0 to 100%)
3	Blue (0 to 100%)
4	Color macros (0 to 15 off, 16+ macros)
5	Strobe / speed / sound sens. (set by ch 6)
6	Mode / programs
7	Master dimmer
8	Dimmer speed

VENUE TETRA BAR

6 CHANNEL · RGBA, WHOLE BAR

1	Red (all zones)
2	Green (all zones)
3	Blue (all zones)
4	Amber (all zones)
5	Master dimmer
6	Strobe

6 ch has no per-zone control. Higher modes (16, 28 ch) split the 4 zones.

CHAUVET DJ KINTA FX ILS

9 CHANNEL · DERBY + LASER + STROBE (PARKED)

1	Effect select / blackout
2	Program speed / sound sens.
3	Manual color (when ch 1 = 0 to 9)
4	Derby strobe
5	Derby motor (index / rotate)
6	Pattern (1 to 18)
7	Laser color
8	Laser strobe
9	Laser rotation

Ch 1 picks which effects run (e.g. 150 to 184 beams only, 220 to 255 laser only); set ch 1 to 0 to 9 to drive color and pattern manually on ch 3 to 9. Laser color (ch 7): 10 to 49 red, 50 to 89 green, 90 to 129 both. **Laser safety:** keep beams 3m / 10ft above the floor, never into eyes, audience, or reflective surfaces.

◆ MARQ GESTURE BEAM 400 – 15 CH MOVING BEAM (SOUND BOOTH FOLLOW SPOT)

Patched at DMX 1 to 15, in the sound booth, run as a manual follow spot via an Xbox controller (no spot booth). 15 ch (an 8 ch slim mode also exists). Value ranges below are verified from the manual. The slot order is the standard 15 ch layout for this style of beam: confirm it on the fixture menu before patching.

1	Pan (0 to 540°)	9	Dimmer (master)
2	Pan fine	10	Focus (motorized + frost)
3	Tilt (0 to 270°)	11	Prism (in / out)
4	Tilt fine	12	Prism rotation
5	Movement speed	13	Movement macros
6	Color wheel	14	Macro speed
7	Gobo wheel	15	Reset / special functions
8	Shutter / strobe		

Color wheel (ch 6): 0 white, then red, orange, green, light blue, purple, yellow, blue, pink, then color indexing and CW / CCW scroll. **Shutter (ch 8):** 0 to 3 closed, 4 to 7 open, 8 to 76 strobe slow to fast, 77 to 145 pulse, 146 to 215 random strobe, 216 to 255 open. **Pan / tilt (ch 1 to 4)** are the follow-spot axes the Xbox controller drives; **focus (ch 10)** sharpens the edge on the actor.

◆ CHANNELS 5 + 6 – HOW THE 3 RGB PARS BEHAVE

Channel 6 is the brain, channel 5 is the modifier. What you set on channel 6 decides what channel 5 controls:

CHANNEL 6 SETTING	CHANNEL 5 BECOMES	CHANNEL 5 VALUES
0 to 31	Strobe	0 to 15 off, 16 to 255 slow to fast
32 to 224	Effect speed	0 to 255 slow to fast
225 to 255	Sound sensitivity	0 to 10 off, 11 to 255 low to high

CHANNEL 6 PROGRAM BANDS

0 to 31	No function (manual color)
32 to 127	Pulse / ramp effects
128 to 159	Color fade chase
160 to 191	Color jump, 3 color
192 to 224	Color jump, 7 color
225 to 255	Sound-active

PER-FIXTURE WORDING

Bands are identical across all three. Only the labels differ: ThinTri calls the 32 to 127 band "ramp strobe," the Chauvets call it "pulse." Macro color counts vary slightly (COREpar lists 7 and 18 color snaps). Treat the bands above as the working reference and confirm exact counts on the unit if a specific macro matters.

CUE RULE For any look where you mix color yourself, **park channel 6 at 0** on every par (channel 5 at 0 too). That keeps each fixture from running its own chase against your cues. Drive **color on ch 1 to 3**, **intensity on ch 7**, ignore the rest unless you want an effect.