

INPUT / OUTPUT LIST



X32 Rack patch reference. **Plug your playback device into the Aux In on the desk**; everything else below is already wired. “Open” channels are free for show-specific use.

INPUT CHANNELS

ABOVE-STAGE SNAKE • 6-CHANNEL

1	Overhead Left	
2	Overhead Right	
3	Overhead Center	
4	Overhead — Movable	VARIES BY SHOW
5	Open	SHOW-DEPENDENT
6	Open	SHOW-DEPENDENT

DIRECT INPUTS

7	Open	
8	Open	

GAS-PIPE SNAKE • CH 9–16 = SNAKE SPOTS 1–8

9	Open	SNAKE 1
10	Open	SNAKE 2
11	Wireless handheld 1	SNAKE 3
12	Wireless handheld 2	SNAKE 4
13	Open	SNAKE 5
14	Open	SNAKE 6
15	Open	SNAKE 7
16	Open	SNAKE 8

SUB OUTPUTS

- 1 Subwoofer
- 2 Rear Center
- 3 Open
- 4 Gallery
- 5 Open
- 6 Side Stage

Main L/R = House Mains. House Mains, Side Stage (out 6) & Gallery (out 4) are level-matched — don’t touch individual zones. **SOP 1**

AUX INPUT

Aux In — the aux cable on the desk. Plug in your playback device; set its level on **DCA 1**.

DCA GROUPING

- DCA 1** Non-vocals / playback — the Aux In.
- DCA 2** Overhead mics — channels 1–4.
- DCA 3** Wireless handhelds — channels 11 & 12.