



START 01

CONNECT

Plug your playback device into the **aux cord on the desk**.

START 02

POWER UP

Press **START**, upper-left of the rack. The sequencer powers everything up in order.

START 03

SET LEVEL

Turn the **selector** ① to DCA 1, then raise the **CHANNEL LEVEL** ② knob.

THE X32 RACK — KEY CONTROLS



- ① **Selector** (under the “25” display) — turn it to choose **DCA 1, 2, or 3**.
- ② **CHANNEL LEVEL** — sets the volume of whichever DCA is selected.
- ③ **MAIN LR** (far right) — the master. Keep it at **noon** (it’s lit).
- ④ **TALK** — press & hold, speak into the mic mounted above it (talkback).

To **mute / unmute** a DCA: select it with ①, then press the white **MUTE** button.

Rack care: No food or drink on the audio rack. The desk is fine — just don’t make a mess.

THE THREE DCAS

DCA 1 **Music / non-vocals.** Your plugged-in playback. Live but quiet at power-up — bring it up. **DEFAULT LIVE**

DCA 2 **Overhead mics.** Unmute & adjust only if overheads are needed. **DEFAULT MUTED**

DCA 3 **Wireless handhelds.** Unmute after they’re powered & connected. **DEFAULT MUTED**

House Mains, Side Stage & Gallery are pre-balanced to one unified level. **Don’t touch the individual zones** — the DCAs are all you need.

WIRELESS HANDHELDS

Two **Xvive M5** units, in the sound-booth drawer.

- ① Plug receivers into **spots 3 & 4** in the floor snake (near the gas pipe).
- ② Power on each **receiver and transmitter**; wait for a **solid color** = connected (blinking = not yet).
- ③ At the board, select **DCA 3** & press **MUTE** to unmute, then set level.

ADVANCED — INDIVIDUAL TRIMS

Select channel

11

(snake 3) or

12

(snake 4) to balance the two handhelds against each other. DCA 3 stays the overall level.

TALKBACK

④ TO TALK THROUGH THE SYSTEM

Press the **TALK** button and speak into the mic mounted above it. Release to stop.

IF THERE’S NO SOUND

⚠ CHECK THESE FIRST

- A **DCA is turned down** — select it ① and check the **CHANNEL LEVEL** ②.
- A **MUTE is on** — select the DCA ① and make sure the white **MUTE** button isn’t lit.
- The **MAIN LR knob** ③ **got bumped** — it should sit at **noon** (it lights up).
- Handhelds silent? Receiver/transmitter must be a **solid color**, and DCA 3 unmuted.

SHUTDOWN

- ① If **handhelds were used**: turn them off, **mute DCA 3**, and plug them into the desk **USB-C** cords to charge — they can’t go in the drawer while charging.
- ② Press **OFF** on the sequencer — it powers everything down in reverse order.