Miles	**36,000**	**42,000**	**48,000**	**54, 000**
(Kilometers)	**(58 000)**	**(67 000)**	**(77 000)**	**(86 000)**
[Months]	**[36]**	**[42]**	**[48]**	**[54]**
Change the engine oil and engine oil filter.	X	X	X	X
Rotate the tires.	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X	
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Inspect the brake linings.	X			X

Miles	**60,000**	**66,000**	**72,000**	**78,000**
(Kilometers)	**(96 000)**	**(106 000)**	**(115 000)**	**(125 000)**
[Months]	**[60]**	**[66]**	**[72]**	**[78]**
Change the engine oil and engine oil filter.	X	X	X	X
Rotate the tires.	X	X	X	X
Inspect the engine air filter element, and replace if necessary.	X			
Inspect the PCV Valve, and replace if necessary. ◇	X			
Replace the ignition cables (2.4L Only).	X			
Replace the spark plugs.	X			
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X	
Inspect the brake linings.			X	
Inspect the drive belt, and replace as needed.	X			
Inspect the drive belt, and replace as needed. Not required if belt was previously replaced.			X	
Flush and replace the engine coolant/anti-freeze at 60 months, if not done at 102,000 miles (163 000 km).	X			
Inspect the manual transmission fluid, add as necessary.	X			
Inspect transfer case fluid.	X			

Miles	**84,000**	**90,000**	**96,000**	**102, 000**
(Kilometers)	**(134 000)**	**(144 000)**	**(154 000)**	**(163 000)**
[Months]	**[84]**	**[90]**	**[96]**	**[102]**
Change the engine oil and engine oil filter.	X	X	X	X
Rotate the tires.	X	X	X	X
Inspect the engine air filter element, and replace if necessary.		X		
Inspect the PCV Valve, and replace if necessary. ◇		X		
Replace the spark plugs.		X		
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X	
Inspect the brake linings.		X		
Inspect the drive belt, and replace as needed. Not required if previously replaced.		X		X