SUSPENSION

TABLE OF CONTENTS

	page
FRONT	1
REAR	12
WHEEL ALIGNMENT	16

FRONT

TABLE OF CONTENTS

	page
FRONT	
DESCRIPTION	1
STANDARD PROCEDURE - LUBRICATION	2
SPECIFICATIONS	
TORQUE CHART	2
SPECIAL TOOLS	
FRONT SUSPENSION	3
BUSHINGS	
REMOVAL	3
INSTALLATION	3
HUB / BEARING	
DESCRIPTION	4
OPERATION	4
REMOVAL	4
INSTALLATION	5
JOUNCE BUMPER	
DESCRIPTION	5
KNUCKLE	
REMOVAL	5
INSTALLATION	6
LOWER BALL JOINT	
REMOVAL	6
LOWER CONTROL ARM	
DESCRIPTION	7
OPERATION	7
REMOVAL	7
INSTALLATION	8
SHOCK	
DESCRIPTION	8
OPERATION	8
DIAGNOSIS AND TESTING - SHOCK ABSORBER	8
REMOVAL	8
INSTALLATION	9
SPRING	
DESCRIPTION	9
OPERATION	9
REMOVAL	9
INSTALLATION	9
STABILIZER BAR	
DESCRIPTION	9
OPERATION	9
REMOVAL	9
INSTALLATION	10
TRACK BAR	
DESCRIPTION	10
OPERATION	10
REMOVAL	10
INSTALLATION	10
UPPER BALL JOINT	
REMOVAL	10
UPPER CONTROL ARM	
DESCRIPTION	11
OPERATION	11
REMOVAL	11
INSTALLATION	11

FRONT

DESCRIPTION

FRONT SUSPENSION

The front suspension is a link/coil design comprised of:

- Shock absorbers
- Jounce Bumper
- Coil springs
- Upper and lower suspension arms
- Stabilizer bar
- Track bar