(5) Install axle washer and nut. Tighten nut to 237 N·m (175 ft. lbs.) and install nut retainer and cotter pin (Fig. 30).