INSTALLATION

(1) Clean axle shaft and apply a thin film of Mopar Wheel Bearing Grease or equivalent to the shaft splines, seal contact surface and hub bore.

(2) Install brake rotor shield on knuckle.

(3) Install axle shaft into differential side gears.

(4) Install hub bearing and tighten bolts to 102 N·m (75 ft. lbs.).

(5) Install axle washer and nut. Tighten nut to 237 N·m (175 ft. lbs.) and install nut retainer and cotter pin (Fig. 30).