REAR AXLE - 216RBI

TABLE OF CONTENTS

page

REAR AXLE - 216RBI
DIAGNOSIS AND TESTING 131
REMOVAL 135
INSTALLATION 135
ADJUSTMENTS 136
SPECIFICATIONS - 216RBI 144
SPECIAL TOOLS 145
SHAFTS-AXLE
REMOVAL 148
INSTALLATION 148
BEARINGS-AXLE
REMOVAL 148
INSTALLATION 149
SEAL-PINION
REMOVAL 150
INSTALLATION 151
COVER-DIFFERENTIAL
REMOVAL 152
INSTALLATION 152
DIFFERENTIAL
REMOVAL 153
DISASSEMBLY 154
ASSEMBLY 154
INSTALLATION 155

page

DIFFERENTIAL-TRAC-LOK
DESCRIPTION 155
OPERATION 155
DIAGNOSIS AND TESTING 156
DISASSEMBLY 156
ASSEMBLY 159
DIFFERENTIAL-TRU-LOK
DESCRIPTION 160
OPERATION 160
DIAGNOSIS AND TESTING 160
REMOVAL 161
DISASSEMBLY 163
ASSEMBLY 165
INSTALLATION 166
DIFFERENTIAL PUMP-TRU-LOK
REMOVAL 167
INSTALLATION 167
BEARINGS-DIFFERENTIAL CASE
REMOVAL 168
INSTALLATION 169
GEAR-PINION/RING
REMOVAL 169
INSTALLATION 171

REAR AXLE - 216RBI

DIAGNOSIS AND TESTING

GEAR NOISE

Axle gear noise can be caused by insufficient lubricant, incorrect backlash, incorrect pinion depth, tooth contact, worn/damaged gears, or the carrier housing not having the proper offset and squareness.

Gear noise usually happens at a specific speed range. The noise can also occur during a specific type of driving condition. These conditions are acceleration, deceleration, coast, or constant load.

When road testing, first warm-up the axle fluid by driving the vehicle at least 5 miles and then accelerate the vehicle to the speed range where the noise is the greatest. Shift out-of-gear and coast through the peak-noise range. If the noise stops or changes greatly:

- Check for insufficient lubricant.
- Incorrect ring gear backlash.
- Gear damage.

Differential side gears and pinions can be checked by turning the vehicle. They usually do not cause noise during straight-ahead driving when the gears are unloaded. The side gears are loaded during vehicle turns. A worn pinion shaft can also cause a snapping or a knocking noise.

BEARING NOISE

The axle shaft, differential and pinion bearings can all produce noise when worn or damaged. Bearing noise can be either a whining, or a growling sound.

Pinion bearings have a constant-pitch noise. This noise changes only with vehicle speed. Pinion bearing noise will be higher pitched because it rotates at a faster rate. Drive the vehicle and load the differential. If bearing noise occurs, the rear pinion bearing is the source of the noise. If the bearing noise is heard during a coast, the front pinion bearing is the source.

Differential bearings usually produce a low pitch noise. Differential bearing noise is similar to pinion bearing noise. The pitch of differential bearing noise is also constant and varies only with vehicle speed.

Axle shaft bearings produce noise and vibration when worn or damaged. The noise generally changes when the bearings are loaded. Road test the vehicle. Turn the vehicle sharply to the left and to the right.