Kilometers **(Miles)** **[Months]**	**72 000** **(45,000)** **[36]**	**84 000** **(52,500)** **[42]**	**96 000** **(60,000)** **[48]**	**108 000** **(67,500)** **[54]**
Inspect the engine air filter element, replace if necessary.			X	
Replace the ignition cables (2.4L Only).			X	
Inspect the PCV Valve, replace if necessary ◇.			X	
Replace the spark plugs.			X	
Lubricate the steering and suspension ball joints.	X		X	
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Inspect Auto Tension Drive Belt, and replace if necessary.			X	
Inspect the brake linings.	X			X
Inspect the transfer case fluid.			X	

Kilometers **(Miles)** **[Months]**	**120 000** **(75,000)** **[60]**	**132 000** **(82,500)** **[66]**	**144 000** **(90,000)** **[72]**	**156 000** **(97,500)** **[78]**
Change the engine oil and engine oil filter.	X	X	X	X
Rotate the tires.	X	X	X	X
Inspect the engine air filter element, replace if necessary.			X	
Inspect the PCV Valve, replace if necessary. ◇			X	
Replace the spark plugs.			X	
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X	
Inspect the brake linings.			X	
Inspect the drive belt, and replace as needed. Not required if belt was previously replaced.	X		X	
Flush and replace the engine coolant at 60 months, regardless of mileage.	X			
Inspect transfer case fluid.			X	

Kilometers **(Miles)** **[Months]**	**168 000** **(105,000)** **[84]**	**180 000** **(112,500)** **[90]**	**192 000** **(120, 000)** **[96]**
Change the engine oil and engine oil filter.	X	X	X
Rotate the tires.	X	X	X
Inspect the engine air filter element, replace if necessary.			X
Replace the ignition cables (2.4L Only).			X
Inspect the PCV Valve, replace if necessary. ◇			X
Replace the spark plugs.			X
Lubricate the steering linkage joints and outer tie rod ends.	X	X	X
Lubricate the steering and suspension ball joints.	X		X
Inspect the brake linings.		X	
Replace the timing belt (2.4L Only).			X