Kilometers	**53 000**	**58 000**	**62 000**	**67 000**	**72 000**
(Miles)	**(33,000)**	**(36,000)**	**(39,000)**	**(42,000)**	**(45,000)**
Change the engine oil and engine oil filter.	X	X	X	X	X
Rotate the tires.		X		X	
Inspect the engine air filter element, replace if necessary.					X
Lubricate the steering linkage tie rod ends.	X	X	X	X	X
Lubricate the steering and suspension ball joints.		X		X	
Inspect the brake linings.		X			
Drain and refill the front and rear axle fluid‡		X			
Inspect the drive belt and replace as needed.					X

Kilometers	**77 000**	**82 000**	**86 000**	**91 000**	**96 000**
(Miles)	**(48,000)**	**(51,000)**	**(54,000)**	**(57,000)**	**(60,000)**
Change the engine oil and engine oil filter.	X	X	X	X	X
Rotate the tires.	X		X		X
Inspect the engine air filter element, replace if necessary.					X
Inspect the PCV Valve, replace if necessary. ◇					X
Inspect the ignition cables, replace if necessary (2.4L Only).					X
Replace the spark plugs.					X
Lubricate the steering linkage tie rod ends.	X	X	X	X	X
Lubricate the steering and suspension ball joints.	X		X		X
Inspect the brake linings.	X				X
Drain and refill the front and rear axle fluid‡	X				X
Drain and refill the automatic transmission fluid, and replace main sump filter.					X
Inspect the drive belt and replace as needed. Not required if belt was previously.					X
Drain and refill the transfer case fluid.					X

Kilometers	**101 000**	**106 000**	**110 000**	**115 000**	**120 000**
(Miles)	**(63,000)**	**(66,000)**	**(69,000)**	**(72,000)**	**(75,000)**
Change the engine oil and engine oil filter.	X	X	X	X	X
Rotate the tires.		X		X	
Inspect the engine air filter element, replace if necessary.					X
Lubricate the steering linkage tie rod ends.	X	X	X	X	X
Lubricate the steering and suspension ball joints.		X		X	
Inspect the brake linings.				X	
Drain and refill the front and rear axle fluid‡				X	
Inspect the drive belt and replace as needed. Not required if belt was previously replaced.					X