ENGINE

TABLE OF CONTENTS

page

COOLANT
DESCRIPTION
DESCRIPTION - ENGINE COOLANT 23
DESCRIPTION - HOAT COOLANT 23
OPERATION 24
COOLANT RECOVERY CONTAINER
DESCRIPTION 24
OPERATION 24
REMOVAL 25
INSTALLATION 25
ENGINE BLOCK HEATER
DESCRIPTION 25
OPERATION 25
REMOVAL
REMOVAL - 2.4L 25
REMOVAL - 4.0L 25
INSTALLATION
INSTALLATION - 2.4L 26
INSTALLATION 4.0L 26
ENGINE COOLANT TEMPERATURE SENSOR
DESCRIPTION 27
OPERATION 27
REMOVAL 27
INSTALLATION 27
ENGINE COOLANT THERMOSTAT
DESCRIPTION 28
OPERATION 28
REMOVAL
2.4L 28
4.0L 28
INSTALLATION
2.4L 29
4.0L 29
FAN DRIVE VISCOUS CLUTCH
DESCRIPTION 30
OPERATION 31
DIAGNOSIS AND TESTING
VISCOUS FAN DRIVE 31
REMOVAL 32
INSTALLATION 32
RADIATOR
DESCRIPTION 32

page

OPERATION 33
DIAGNOSIS AND TESTING - RADIATOR
COOLANT FLOW 33
REMOVAL 33
CLEANING 35
INSPECTION 35
INSTALLATION 36
WATER PUMP - 2.4L
DESCRIPTION 36
OPERATION 36
DIAGNOSIS AND TESTING
WATER PUMP 36
REMOVAL - 2.4L 37
INSTALLATION - 2.4L 37
WATER PUMP - 4.0L
DESCRIPTION 37
OPERATION 38
REMOVAL 38
INSTALLATION 40
RADIATOR PRESSURE CAP
DESCRIPTION 40
OPERATION 41
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - RADIATOR
CAP-TO-FILLER NECK SEAL 41
DIAGNOSIS AND TESTING - RADIATOR
CAP 41
CLEANING 42
INSPECTION 42
RADIATOR FAN
DESCRIPTION 42
REMOVAL
2.4L 42
4.0L 43
CLEANING 43
INSPECTION 43
INSTALLATION
2.4L 43
4.0L 43
RADIATOR FAN RELAY
DESCRIPTION 43