AUDIO / VIDEO

TABLE OF CONTENTS

page

AUDIO
DESCRIPTION 1
OPERATION 1
DIAGNOSIS AND TESTING - AUDIO 1
AMPLIFIED SUBWOOFER
DESCRIPTION 3
OPERATION 3
DIAGNOSIS AND TESTING - AMPLIFIED SUBWOOFER 3
REMOVAL 3
INSTALLATION 3
ANTENNA BODY & CABLE
DESCRIPTION 4
DIAGNOSIS AND TESTING - ANTENNA BODY AND CABLE 4
REMOVAL 5
INSTALLATION 5
ANTENNA - SATELLITE RADIO
OPERATION 6
REMOVAL 6
INSTALLATION 6

page

RADIO
DESCRIPTION 6
OPERATION 6
REMOVAL 7
INSTALLATION 7
RADIO NOISE SUPPRESSION COMPONENTS
DESCRIPTION 8
DIAGNOSIS AND TESTING - RADIO NOISE SUPPRESSION COMPONENTS 8
REMOVAL 8
INSTALLATION 9
RECEIVER - SATELLITE RADIO
REMOVAL 9
INSTALLATION 9
SPEAKER
DESCRIPTION 9
OPERATION 9
DIAGNOSIS AND TESTING - SPEAKER 9
REMOVAL 10
INSTALLATION 11

AUDIO

DESCRIPTION

Several combinations of radio receivers and speaker systems are offered.

The audio system includes the following components:

- Amplified sub woofer (if equipped)
- Antenna (Radio, Satellite)
- Radio noise suppression components
- Radio receiver
- Speakers

Certain functions and features of the audio system rely upon resources shared with other electronic modules in the vehicle over the Programmable Communication Interface (PCI) bus network. The data bus network allows the sharing of sensor information. For diagnosis of these electronic modules or of the data bus network, the use of a DRB III® scan tool and the proper Diagnostic Procedures manual are recommended.

OPERATION

The audio system components are designed to provide audio entertainment and information through the reception, tuning and amplification of locally broadcast radio signals in both the Amplitude Modulating (AM) and Frequency Modulating (FM) commercial frequency ranges.

The audio system components operate on battery current received through a fuse in the Junction Block (JB) on a fused ignition switch output (run-acc) circuit so that the system will only operate when the ignition switch is in the Run or Accessory positions.

DIAGNOSIS AND TESTING - AUDIO

Any diagnosis of the Audio system should begin with the use of the DRB III® diagnostic tool. For information on the use of the DRB III®, refer to the appropriate Diagnostic Service Manual.

For complete circuit diagrams, refer to the appropriate wiring information.

WARNING: On vehicles equipped with air bags, (refer to electrical/restraints) before attempting any steering wheel, steering column, or instrument panel component diagnosis or service. Failure to take the proper precautions could result in accidental airbag deployment and possible personal injury.