Audio System Diagnosis		
CONDITION	POSSIBLE CAUSE	CORRECTION
NO AUDIO.	1. Fuse inoperative.	1. Check radio fuse and Ignition-Off Draw fuse in Power Distribution Center. Replace fuses, if required.
	2. Radio connector damaged.	2. Check for loose or corroded radio connector. Repair, if required.
	3. Wiring damaged.	3. Check for battery voltage at radio connector. Repair wiring, if required.
	4. Ground damaged.	4. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required.
	5. Radio inoperative.	5. Exchange or replace radio, if required.
	6. Speakers inoperative.	6. Refer to speaker diagnosis.
NO DISPLAY.	1. Fuse inoperative.	1. Check radio fuse and Ignition-Off Draw fuse in Power Distribution Center. Replace fuses, if required.
	2. Radio connector damaged.	2. Check for loose or corroded radio connector. Repair, if required.
	3. Wiring damaged.	3. Check for battery voltage at radio connector. Repair wiring, if required.
	4. Ground damaged.	4. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required.
	5. Radio inoperative.	5. Exchange or replace radio, if required.
CLOCK WILL NOT KEEP SET TIME.	1. Fuse inoperative.	1. Check ignition-off draw fuse. Replace fuse, if required.
	2. Radio connector damaged.	2. Check for loose or corroded radio connector. Repair, if required.
	3. Wiring damaged.	3. Check for battery voltage at radio connector. Repair wiring, if required.
	4. Ground damaged.	4. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required.
	5. Radio inoperative.	5. Exchange or replace radio, if required.
POOR RADIO RECEPTION.	1. Antenna inoperative.	1. See antenna diagnosis, in this group. Repair or replace antenna, if required.
	2. Ground damaged.	2. Check for continuity between radio chassis and a known good ground. There should be continuity. Repair ground, if required.
	3. Radio inoperative.	3. Exchange or replace radio, if required.
NO/POOR TAPE OPERATION.	1. Tape damaged.	1. Insert known good tape and test operation.
	2. Foreign objects behind tape door.	2. Remove foreign objects and test operation.
	3. Dirty cassette tape head.	3. Clean head with Mopar Cassette Head Cleaner.
	4. Radio inoperative	4. Exchange or replace radio, if required.