INSTALLATION

ENGINE - TO - BODY GROUND STRAP

(1) Position the engine-to-body ground strap in the engine compartment.

(2) Position the engine-to-body ground strap eyelet over the stud on the left upper rear corner of the engine cylinder head.

(3) Install and tighten the nut that secures the engine-to-body ground strap eyelet to the stud on the left upper rear corner of the engine cylinder head. Tighten the nut to 5.6 N·m (50 in. lbs.).

(4) Install and tighten the screw that secures the engine-to-body ground strap eyelet to the dash panel. Tighten the screw to 48.5 N·m (430 in. lbs.).

(5) Install and tighten the screw that secures the engine-to-body ground strap eyelet to the hood panel center reinforcement. Tighten the screw to 1.9 N·m (17 in. lbs.).

RECEIVER - SATELLITE RADIO

REMOVAL

NOTE: A battery reconnect procedure must be performed anytime the battery has been disconnected. (Refer to 8 - ELECTRICAL/BATTERY SYSTEM - STANDARD PROCEDURE).



Fig. 5 RECEIVER - SATELLITE RADIO

1 - Satellite Receiver
2 - Electrical Connector
3 - Mounting Bolts

(1) Disconnect and isolate the battery negative cable.

(2) Disconnect the electrical connectors. (Fig. 5)

(3) Remove the mounting bolts.

INSTALLATION

NOTE: A battery reconnect procedure must be performed anytime the battery has been disconnected. (Refer to 8 - ELECTRICAL/BATTERY SYSTEM - STANDARD PROCEDURE).

(1) Install the mounting bolts.

(2) Connect the electrical connectors

(3) Connect the battery negative cable.

SPEAKER

DESCRIPTION

The standard equipment speaker system includes four full-range speakers. The two front speakers are mounted behind a removable bezel located on each outboard end of the lower instrument panel. With the premium speaker system, the standard front speakers are replace with an enclosure assembly that includes a 4 inch speaker and a 1 inch tweeter. The two rear speakers are mounted behind a grille located on each outboard end of the sport bar, above the rear seating area of the vehicle.

OPERATION

Two wires connected to each speaker, one feed circuit (+) and one return circuit (–), allow the audio output signal electrical current to flow through the speaker voice coil.

DIAGNOSIS AND TESTING - SPEAKER

Any diagnosis of the Audio system should begin with the use of the DRB III® diagnostic tool. For information on the use of the DRB III®, refer to the appropriate Diagnostic Service Manual.

For complete circuit diagrams, refer to the appropriate wiring information.

WARNING: Disable the airbag system before attempting any steering wheel, steering column, seat belt tensioner, side airbag, or instrument panel component diagnosis or service. Disconnect and isolate the battery negative (ground) cable, then wait two minutes for the airbag system capacitor to discharge before performing further diagnosis or service. This is the only sure way to disable the airbag system. Failure to take the proper precautions could result in accidental airbag deployment and possible personal injury.

CAUTION: The speaker output of the radio is a "floating ground" system. Do not allow any speaker lead to short to ground, as damage to the radio may result.