5 VOLT SUPPLIES

Primary 5-volt supply:

- supplies the required 5 volt power source to the Crankshaft Position (CKP) sensor.
- supplies the required 5 volt power source to the Camshaft Position (CMP) sensor.
- supplies a reference voltage for the Manifold Absolute Pressure (MAP) sensor.
- supplies a reference voltage for the Throttle Position Sensor (TPS) sensor.

Secondary 5-volt supply:

- supplies the required 5 volt power source to the oil pressure sensor.
- supplies the required 5 volt power source for the Vehicle Speed Sensor (VSS) (if equipped).
- supplies the 5 volt power source to the transmission pressure sensor (if equipped with an RE automatic transmission).

IGNITION CIRCUIT SENSE

The ignition circuit sense input tells the PCM the ignition switch has energized the ignition circuit.

Battery voltage is also supplied to the PCM through the ignition switch when the ignition is in the RUN or START position. This is referred to as the “ignition sense” circuit and is used to ″wake up” the PCM. Voltage on the ignition input can be as low as 6 volts and the PCM will still function. Voltage is supplied to this circuit to power the PCM's 8-volt regulator and to allow the PCM to perform fuel, ignition and emissions control functions.

REMOVAL

Use the drb scan tool to reprogram the new powertrain control module (pcm) with the vehicles original identification number (vin) and the vehicles original mileage. If this step is not done, a diagnostic trouble code (dtc) may be set.



Fig. 5 PCM MOUNTING - LEFT HAND DRIVE

1 - MOUNTING SCREWS (3)
2 - PCM
3 - PCM ELECTRICAL CONNECTORS



Fig. 6 PCM MOUNTING - RIGHT HAND DRIVE

1 - PCM
2 - MOUNTING SCREWS (3)
3 - PCM ELECTRICAL CONNECTORS

To avoid possible voltage spike damage to the PCM, ignition key must be off, and negative battery cable must be disconnected before unplugging PCM connectors.

(1) Disconnect negative battery cable at battery.

(2) Remove plastic shields from over four electrical connectors. Shields snap to connectors.

(3) Carefully unplug four electrical connectors (3) (Fig. 5) or (Fig. 6) from PCM.

(4) Remove three PCM mounting bolts (1) or (2) and remove PCM from vehicle.