(5) Remove the upper and lower shrouds from the steering column.

(6) On models equipped with a manual transmission, remove the screws that secure the multi-function switch assembly to the upper steering column housing.

(7) Disconnect the cross body wire harness connector for the SKIM from the SKIM connector (Fig. 11).