TORQUE

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.
Battery Terminal Clamp Pinch-Bolt Hex Nut	8.5	-	75
Starter Solenoid B(+) Terminal Stud Nut	10	-	90
Battery Negative Cable Ground Eyelet Terminal To Engine Block Nut	17	-	150
Generator Output Terminal Stud Nut	8.5	-	75
Power Distribution Center B(+) Terminal Stud Nut	11.5	-	105
Battery Hold Down J-Bolt Nut	4.5	-	42
Battery Negative Cable Eyelet Terminal To The Dash Panel Bolt	49	36	-
Battery Tray Screw	22.5	-	200