located between the dash panel and the rear of the front wheelhouse inner panel in the engine compartment. Tighten the screws to 22.5 N·m (200 in. lbs.).

(4) Install the battery onto the battery tray (Refer to 8 - ELECTRICAL/BATTERY SYSTEM/BATTERY - INSTALLATION).