LAMPS

TABLE OF CONTENTS

page

LAMPS/LIGHTING - EXTERIOR 1

page

LAMPS/LIGHTING - INTERIOR 34

LAMPS / LIGHTING - EXTERIOR

TABLE OF CONTENTS

page

LAMPS/LIGHTING - EXTERIOR
DESCRIPTION - TURN SIGNAL & HAZARD WARNING SYSTEM 2
OPERATION - TURN SIGNAL & HAZARD WARNING SYSTEM 2
WARNING 3
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - TURN SIGNAL & HAZARD WARNING SYSTEM 3
DIAGNOSIS AND TESTING - HEADLAMP SYSTEM 4
SPECIFICATIONS
LAMPS/LIGHTING - EXTERIOR 6
SPECIAL TOOLS
HEADLAMP ALIGNMENT 6
BRAKE LAMP SWITCH
DESCRIPTION 6
OPERATION 6
DIAGNOSIS AND TESTING - BRAKE LAMP SWITCH 7
REMOVAL 7
INSTALLATION 7
ADJUSTMENTS
ADJUSTMENT 7
CENTER HIGH MOUNTED STOP LAMP UNIT
REMOVAL 8
INSTALLATION 8
CENTER HIGH MOUNTED STOP LAMP
REMOVAL 8
INSTALLATION 8
COMBINATION FLASHER
DESCRIPTION 9
OPERATION 9
REMOVAL 9
INSTALLATION 10
DAYTIME RUNNING LAMP MODULE
DESCRIPTION 10
OPERATION 10
DIAGNOSIS AND TESTING - DAYTIME RUNNING LAMP SYSTEM 11

page

REMOVAL 11
INSTALLATION 12
FOG LAMP UNIT
DIAGNOSIS AND TESTING - FRONT FOG LAMP SYSTEM 12
REMOVAL 13
INSTALLATION 13
ADJUSTMENTS
FRONT FOG LAMP AIMING 13
FOG LAMP
REMOVAL 14
INSTALLATION 14
FOG LAMP RELAY
DESCRIPTION 15
OPERATION 15
REMOVAL 15
INSTALLATION 15
FOG LAMP UNIT - REAR
DESCRIPTION 15
OPERATION 15
DIAGNOSIS AND TESTING - REAR FOG LAMP 16
REMOVAL 16
INSTALLATION 17
FOG LAMP - REAR
REMOVAL 17
INSTALLATION 17
FRONT PARK/TURN SIGNAL LAMP UNIT
DESCRIPTION 18
OPERATION 18
REMOVAL 18
INSTALLATION 18
FRONT PARK/TURN SIGNAL LAMP
REMOVAL 18
INSTALLATION 18
HEADLAMP
DESCRIPTION 18
OPERATION 18
REMOVAL 19
INSTALLATION 19