CONDITION	POSSIBLE CAUSES	CORRECTION
HEADLAMPS ARE DIM WITH ENGINE IDLING OR IGNITION TURNED OFF	1. Loose or corroded battery cables.	1. Clean and secure battery cable clamps and posts.
	2. Loose or worn generator drive belt.	2. Adjust or replace generator drive belt.
	3. Charging system output too low.	3. Test and repair charging system. (Refer to 8 - ELECTRICAL/CHARGING - DIAGNOSIS AND TESTING)
	4. Battery has insufficient charge.	4. Test battery state-of-charge. (Refer to 8 - ELECTRICAL/BATTERY SYSTEM/BATTERY - DIAGNOSIS AND TESTING)
	5. Battery is sulfated or shorted.	5. Load test battery. (Refer to 8 - ELECTRICAL/BATTERY SYSTEM/BATTERY - DIAGNOSIS AND TESTING)
	6. Poor lighting circuit ground.	6. Test for voltage drop across ground locations.
	7. Both headlamp bulbs faulty.	7. Replace both headlamp bulbs.
HEADLAMP BULBS BURN OUT FREQUENTLY	1. Charging system output too high.	1. Test and repair charging system. (Refer to 8 - ELECTRICAL/CHARGING - DIAGNOSIS AND TESTING)
	2. Loose or corroded terminals or splices in headlamp circuit.	2. Inspect and repair all connectors and splices.
HEADLAMPS ARE DIM WITH ENGINE RUNNING	1. Charging system output too low.	1. Test and repair charging system. (Refer to 8 - ELECTRICAL/CHARGING - DIAGNOSIS AND TESTING)
ABOVE IDLE*	2. Poor lighting circuit ground.	2. Test for voltage drop across ground locations.
	3. High resistance in headlamp circuit.	3. Test amperage draw of headlamp circuit.
	4. Both headlamp bulbs faulty.	4. Replace both headlamp bulbs.
HEADLAMPS FLASH RANDOMLY	1. Poor lighting circuit ground.	1. Test for voltage drop across ground locations.
	2. High resistance in headlamp circuit.	2. Test amperage draw of headlamp circuit. Should not exceed 30 amps.
	3. Faulty headlamps switch circuit breaker.	3. Replace headlamp switch. (Refer to 8 - ELECTRICAL/LAMPS/LIGHTING - EXTERIOR/HEADLAMP SWITCH - REMOVAL)
	4. Short in headlamp circuit	Test headlamp circuit, repair as necessary.
	4. Loose or corroded terminals or splices in headlamp circuit.	4. Inspect and repair all connectors and splices.
HEADLAMPS DO NOT ILLUMINATE LOW OR HIGH BEAM	1. No voltage to headlamps.	1. Repair open headlamp circuit.
	2. No ground at headlamps.	2. Repair circuit ground.
	3. Faulty headlamp switch.	3. Replace headlamp switch. (Refer to 8 - ELECTRICAL/LAMPS/LIGHTING - EXTERIOR/HEADLAMP SWITCH - REMOVAL)