CONDITION	POSSIBLE CAUSES	CORRECTION
FOG LAMPS ARE DIM WITH ENGINE RUNNING ABOVE IDLE	1. Charging system output too low.	1. Test and repair charging system. (Refer to 8 - ELECTRICAL/CHARGING - DIAGNOSIS AND TESTING)
	2. Poor lighting circuit ground.	2. Test for voltage drop across ground locations.
	3. High resistance in fog lamp circuit.	3. Test amperage draw of fog lamp circuit.
FOG LAMPS FLASH RANDOMLY	1. Poor lighting circuit ground.	1. Test for voltage drop across ground locations.
	2. High resistance in fog lamp circuit.	2. Test amperage draw of fog lamp circuit.
	3. Faulty relay	3. Replace relay
	4. Faulty fog lamp switch.	4. Replace multifunction switch.
	5. Loose or corroded terminals or splices in circuit.	5. Inspect and repair all connectors and splices.
FOG LAMPS DO NOT ILLUMINATE	1. Blown fuse for fog lamp.	1. Replace fuse.
	2. No ground at fog lamps.	2. Repair circuit ground.
	3. High beam headlamps illuminated	3. Switch headlamp beam selector to low beam.
	4. Faulty relay	4. Replace relay
	5. Faulty fog lamp switch.	5. Replace left multifunction switch.
	6. Shorted clockspring.	6. Replace clockspring.
	7. Broken connector terminal or wire splice in fog lamp circuit.	7. Repair connector terminal or wire splice.
	8. Faulty or burned out bulb.	8. Replace bulb.

REMOVAL

(1) Disconnect and isolate the battery negative cable.
(2) Disconnect the fog lamp wire harness connector.
(3) Remove the nut attaching the fog lamp to the front bumper.
(4) Remove the fog lamp.

INSTALLATION

(1) Position the fog lamp on the bumper.
(2) Install the nut attaching the fog lamp to the front bumper.
(3) Connect the fog lamp wire harness connector.
(4) Connect the battery negative cable.
(5) Readjust fog lamps (Refer to 8 - ELECTRICAL/LAMPS/LIGHTING - EXTERIOR/FOG LAMP UNIT - ADJUSTMENTS).

ADJUSTMENTS

FRONT FOG LAMP AIMING

Prepare an alignment screen. A properly aligned fog lamp will project a pattern on the alignment screen 100 mm (4 in.) below the fog lamp centerline and straight ahead (Fig. 9).